

kobold

VK7
System

VORWERK



User manual

EN • 27066-02 • 0223

Table of contents

1	Before you start	5	6.5	Operation.....	30
2	Product overview	6	6.5.1	Switching on and off	30
2.1	Cordless handheld vacuum cleaner and accessory heads ..	6	6.5.2	Selecting the power level.....	31
3	Intended use.....	8	6.5.3	Boost button.....	31
4	For your safety	11	6.6	Smart Home: Bluetooth® and MyKobold app.....	32
4.1	Hazards and safety instructions.....	11	6.6.1	Installing and pairing the MyKobold app.....	32
4.2	Classification of safety warning messages.....	21	6.7	Battery running times	33
4.3	Obligations of the User.....	21	6.8	Storing the cordless handheld vacuum cleaner	33
5	Suitability for different types of floors	23	6.9	Transportation	34
6	Kobold VK7 cordless handheld vacuum cleaner	24	6.9.1	Setting the device to transport mode	35
6.1	Product overview	24	6.10	Factory reset.....	35
6.2	Getting started.....	25	6.11	Maintenance.....	36
6.2.1	Opening and closing the rotating handle.....	25	6.11.1	Spare parts and consumables	36
6.2.2	Attaching and unlocking the accessory head	26	6.11.2	Opening and closing the filter cover.....	36
6.2.3	Standby position	26	6.11.3	Inserting and changing the premium filter bag.....	37
6.3	Charging.....	27	6.11.4	Removing or inserting the battery.....	39
6.3.1	Before charging for the first time	27	6.11.5	Removing, cleaning and inserting the motor protection filter.....	39
6.3.2	Charging with different chargers	27	6.11.6	Replacing fragrance chips.....	41
6.3.3	Charging with the single charger	28	6.12	Technical Data.....	42
6.3.4	Charging a separate battery with the single charger.....	28	6.12.1	Cordless Handheld Vacuum Cleaner	42
6.4	Display.....	29	6.12.2	Single charger.....	43
6.4.1	Charging display	29	7	Kobold EB7 automatic electric floor brush	44
6.4.2	System and power display	29	7.1	Product overview	44

7.2	Suitability for different types of floors	45	8.6.1	Selecting the moisture setting	59
7.3	Operation	46	8.6.2	Overview of moisture settings	60
7.3.1	Selecting the power level.....	46	8.6.3	Recommendations for moisture settings.....	61
7.3.2	Overview of power levels and brush mode.....	46	8.6.4	Vacuum wiping	62
7.3.3	Activating the boost cap	47	8.6.5	Replacing the cleaning cloth ..	63
7.3.4	Personalised cleaning setting.	47	8.6.6	Storage.....	63
7.3.5	Standby position	48	8.6.7	Washing cleaning cloths	63
7.3.6	Vacuuming.....	48	8.7	Maintenance	64
7.3.7	Instructions for use.....	48	8.7.1	Spare parts and consumables	64
7.4	Maintenance	48	8.7.2	Removing the sealing lip frames	64
7.4.1	Spare parts and consumables	49	8.7.3	Mounting the sealing lip frames	65
7.4.2	Checking and cleaning	49	8.7.4	Cleaning the tank	65
7.4.3	Changing the roller brushes....	50	8.8	Technical Data	65
7.4.4	Changing the rear sealing lip ..	51	9	Kobold HD7 hard floor brush.....	66
7.5	Technical Data	51	9.1	Product overview	66
8	Kobold SP7 2-in-1 wet and dry cleaning attachment	52	9.2	Suitability for different types of floors.....	67
8.1	Product overview	52	9.3	Operation.....	68
8.2	Suitability of the cleaning cloths for diverse floor types ..	53	9.3.1	Extending the sealing lip.....	68
8.3	Cleaning cloths	54	9.3.2	Selecting the power level.....	68
8.4	Koboclean.....	54	9.3.3	Overview of power levels	69
8.5	Getting ready for use.....	55	9.3.4	Vacuuming hard floors.....	69
8.5.1	Standby position	55	9.4	Maintenance	69
8.5.2	Releasing the cloth holder	56	9.4.1	Spare parts and consumables	70
8.5.3	Attaching the cleaning cloth to the cloth holder	56	9.4.2	Removing blockages	70
8.5.4	Removing, filling and inserting the tank	57	9.4.3	Changing the bristle plate.....	70
8.5.5	Attaching the cloth holder	58	9.5	Technical Data	71
8.5.6	Personalised cleaning setting.	59	10	Kobold PB7 electric upholstery brush with Kobold MP7/MR7 mattress cleaning set	72
8.6	Operation	59			

10.1	Product overview	72	12.2	Unlocking accessories.....	88
10.2	Operation	73	12.3	Kobold SG7 shoulder strap	89
10.2.1	Overview of power levels and Lavenia mode	73	13	Troubleshooting.....	90
10.2.2	Cleaning upholstery	74	13.1	Troubleshooting by error code	90
10.2.3	Vacuuming surfaces	74	13.2	Troubleshooting by fault description.....	93
10.2.4	Vacuuming crevices.....	74	14	Warranty	103
10.2.5	Cleaning mattresses.....	74	15	Disposal.....	103
10.3	Maintenance	77	15.1	Disposal of the device	103
10.3.1	Spare parts and consumables	77	15.2	Disposal of batteries.....	103
10.3.2	Maintenance of the electric upholstery brush	78	15.3	Disposal of premium filter bags.....	104
10.3.3	Cleaning the mattress freshening accessory.....	79	15.4	Disposal of the packaging.....	104
10.3.4	Cleaning the mattress deep cleaning accessory	80	16	Service	104
10.4	Technical Data	81	17	Manufacturer and Importer	104
11	Kobold PC7 dual battery charger.....	82	18	Declaration of Conformity.....	105
11.1	Product overview	82			
11.2	Connecting the mains cable ...	83			
11.3	Mounting the device on a wall	83			
11.3.1	Selecting a location for the wall mount.....	83			
11.4	Charging with the dual battery charger	84			
11.4.1	Charging for the first time with the dual battery charger	84			
11.4.2	Charging the cordless handheld vacuum cleaner with the dual battery charger .	84			
11.4.3	Charging a separate battery with the dual battery charger .	85			
11.5	Technical Data	86			
12	Kobold accessories	87			
12.1	Nozzle set.....	87			

1 Before you start

Congratulations on the purchase of your new Kobold device.

1. Read the instruction manual carefully before using the device and accessories for the first time.
2. Follow the detailed instructions for use in the following chapters.

2 Product overview


2.1 Cordless handheld vacuum cleaner and accessory heads



Overview of the Kobold VK7 cordless handheld vacuum cleaner, accessory heads and accessories

1 Kobold VK7 cordless handheld vacuum cleaner	4 Kobold HD7 hard floor brush
2 Kobold EB7 automatic electric floor brush	5 Kobold SC7 single charger
3 Kobold SP7 2-in-1 wet and dry cleaning attachment	6 Kobold CA7 charging adaptor for spare battery

Type and range of accessories included may vary. Accessories can be purchased separately. The diagrams in this instruction manual are meant to illustrate the functions of the device and its accessories. The illustrations shown may differ from the actual product with respect to detail and proportions. Drawings of plugs are for illustrative purposes only. The actual product may vary depending on the country.



Overview of the Kobold VK7 cordless handheld vacuum cleaner, accessory heads and accessories

7 Kobold PB7 electric upholstery brush	14 Kobold TR7 telescopic tube
8 Kobold MP7 mattress freshening accessory	15 Kobold CD7 car nozzle
9 Kobold MR7 mattress deep cleaning accessory	16 Kobold TD7 textile nozzle
10 Kobold AD7 adapter for previous accessories	17 Kobold SG7 shoulder strap
11 Kobold FD7 surface nozzle	18 Kobold BY7 battery
12 Kobold VD7 variable nozzle set	19 Kobold PC7 dual battery charger
13 Kobold SB7 extendable suction hose for accessories	20 Kobold mains charging cable for the Kobold PC7 dual battery charger

3 Intended use

Retain this document for future reference. It is an important part of the device and must be kept with it if you pass it on to someone else.

Use the device and accessories only for their intended purpose in order to prevent risks to you and other people and to prevent damage to the device or to other property and equipment.

The device is not intended to be used by children under 8 years of age. Cleaning and user maintenance should not be carried out by children under 8 years of age. This device is not intended to be used by persons (including children aged 8 years and above) with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they are supervised by a person responsible for their safety, or have been given instruction from this person concerning the safe use of the device and understand the hazards involved.

Children must not be allowed to play with the device or the chargers (including the cable and plug).

Cleaning and user maintenance must not be carried out by children aged 8 years and above without supervision.

This appliance may only be used for its intended purpose. No other use is permitted. The manufacturer bears no responsibility for damages resulting from improper use. If the appliance is subject to technical modifications, the warranty and liability for material defects shall be rendered invalid. The manufacturer's obligation to compensate on the basis of product liability and/or the dealer's obligation to compensate for material defects shall no longer apply if technical modifications are made to the product.

When working with the device, please observe all the accompanying documentation as well as the device display. The manufacturer accepts no liability for damages resulting from improper use.

The device complies with the safety regulations of the country in which it has been sold by an authorised Vorwerk organisation. If the device is used in another country, compliance with the local safety standards cannot be guaranteed. Vorwerk therefore assumes no liability for any resulting safety risks for the user.

Kobold VK7 cordless handheld vacuum cleaner

The Kobold VK7 cordless handheld vacuum cleaner is solely intended for removing dirt and dust within domestic areas and is only suitable for indoor use. This also includes use for typical household applications in shops, offices and similar work environments, agricultural operations, by customers in hotels, motels, bed and breakfast operations and similar living environments. The Kobold VK7 cordless handheld vacuum cleaner may only be used with the corresponding Kobold accessories.

Kobold EB7 automatic electric floor brush	Your Kobold EB7 automatic electric floor brush should be used solely for cleaning floors and carpets in domestic areas. The Kobold EB7 automatic electric floor brush may only be used in combination with a Kobold VK7 cordless handheld vacuum cleaner. The Kobold EB7 automatic electric floor brush is intended for use on different types of floors [▶ 23]. The following types of carpet and flooring must not be cleaned with the automatic electric floor brush: fur rugs, flokati rugs, unsealed cork flooring, unsealed soft wood flooring, Belgian granite, delicate natural stone flooring, rough concrete flooring (e.g. washed concrete).
Kobold SP7 2-in-1 wet and dry cleaning attachment	Your Kobold SP7 2-in-1 wet and dry cleaning attachment should be used solely for cleaning hard floors in domestic areas. The Kobold SP7 2-in-1 wet and dry cleaning attachment may only be used in combination with a Kobold VK7 cordless handheld vacuum cleaner. It is intended for use on various types of hard floors [▶ 53]. It is suitable for use on floors that can be wet cleaned according to the manufacturer's recommendations. The following types of flooring must not be wet cleaned: untreated cork flooring, untreated tiled flooring, untreated soft wood flooring.
Kobold HD7 hard floor brush	Your Kobold HD7 hard floor brush should be used solely for cleaning hard floors in domestic areas. The Kobold HD7 hard floor brush may only be used in combination with a Kobold VK7 cordless handheld vacuum cleaner. It is intended for use on the types of hard floors specified in the table Suitability for different types of floors [▶ 67].
Kobold PB7 electric upholstery brush	Your Kobold PB7 electric upholstery brush should be used solely for cleaning in domestic areas. The Kobold PB7 electric upholstery brush may only be used in combination with a Kobold VK7 cordless handheld vacuum cleaner. It is intended only for the care of upholstered furniture.
Kobold MP7/MR7 mattress cleaning set	The Kobold MP7/MR7 mattress cleaning set may only be used in combination with a Kobold VK7 cordless handheld vacuum cleaner and Kobold PB7 electric upholstery brush. It is intended only for the care of mattresses. It is not suitable for upholstered furniture.
Kobold accessories	The extendable Kobold SB7 suction hose for accessories, the Kobold FD7 surface nozzle, the Kobold VD7 variable nozzle, the Kobold TR7 telescopic tube, the Kobold CD7 car nozzle, the Kobold TD7 textile nozzle, the Kobold SG7 shoulder strap and the Kobold AD7 adapter for previous accessories may only be used with the Kobold VK7 cordless handheld vacuum cleaner. These accessories are suitable for a variety of cleaning tasks above floor level. The shoulder strap is intended exclusively for use by adults. The cordless handheld vacuum cleaner must be securely held or safely set down for all above-floor cleaning tasks.
Kobold PC7 dual battery charger	The Kobold PC7 dual battery charger may only be used with the Kobold VK7 modular cleaning system. The Kobold PC7 dual battery charger is intended for charging the Kobold VK7 cordless handheld

vacuum cleaner and one additional Kobold VK7 battery. The Kobold PC7 dual battery charger must not be stored or operated outdoors and must be protected from moisture.

Kobold SC7 single charger The Kobold SC7 single charger must only be used with the Kobold VK7 modular cleaning system. The Kobold SC7 single charger is intended for charging the Kobold VK7 cordless handheld vacuum cleaner. Using the Kobold CA7 charging adapter, a separate battery can be charged. The Kobold SC7 single charger must not be stored or operated outdoors and must be protected from moisture.

4 For your safety

Safety is an essential part of every Vorwerk product. However, the safety of this product can only be ensured if the product is used correctly and the safety warnings are observed.

4.1 Hazards and safety instructions

WARNING

- Risk of electric shock!** **Improper use of the device could cause an electric shock.**
- Do not insert any sharp objects into the electrical contacts.
 - Do not modify the electrical contacts.
- Risk of fire or electric shock!** **If incorrect repairs are performed on the device or corresponding charger/charging unit, this may cause a fire or electric shock.**
- Never attempt to repair the device yourself.
 - Repairs to electrical appliances may only be carried out by a Vorwerk customer service centre, a workshop authorised by Vorwerk or a person with similar qualifications in order to avoid hazards.
 - Defective parts may only be replaced by original replacement parts in order to avoid hazards.
 - In the event of damage to your device, contact Vorwerk customer service.
 - Only operate the charger/charging unit on a connection that has been properly installed by a qualified electrician.
 - Do not attempt to open the charger and repair it yourself. The charger has live parts inside and is not a serviceable component.
- Risk of electric shock!** **Carrying out cleaning when the charger is still plugged in could cause an electric shock.**
- Disconnect the charger and/or connection cable for the charger from the power socket before cleaning.
- Risk of fire or electric shock!** **If you run the device over exposed cables, it could cause a fire, or an electric shock on contact.**
- Never run your device over cables on the floor.
- Risk of electric shock!** **The power cord may be damaged by tensile stress.**
- Never pull the mains plug from the socket by the power cord, only by the plug.
 - Never carry the chargers by the connection cable.

- Risk of electric shock!** If water gets into the electrical components, you could get an electric shock.
- Never clean the charger or charging unit with water, liquid cleaners or a wet cleaning cloth.
 - Do not use the charger or charging unit in damp environments.
 - Never immerse the charger or charging unit in water or other liquids.
 - Never pour water over the charger or charging unit.
 - Do not hold the charger or charging unit under running water.
 - Do not touch the charger or charging unit with wet hands.
- Risk of electric shock!** Drilling mounting holes in the wall could result in an electric shock.
- When drilling (especially near a power socket or light switch), take particular care to ensure that you do not drill through an electric cable.
- Explosion hazard!** The improper handling of the battery or the device could cause an explosion.
- Only use original Vorwerk batteries that are compatible with your device.
 - Never attempt to open, repair or modify the battery. Defective batteries must be replaced by new original Vorwerk batteries.
 - Stop using the battery if it is damaged.
- Explosion hazard!** Improper use of cleaning agents may cause dangerous reactions.
- Do not use any cleaning agents that are oil-based, irritant, ignitable, inflammable or contain solvents or chlorine.
 - Do not add such cleaning agents to the Kobold SPB100 tank.
 - Never mix different cleaning agents and care products.

Risk of fire or explosion!

The device could start to burn if it is exposed to heat, if the power supply unit is covered, or as a result of improper use.

- The device and all its accessories (especially the battery) must never be placed on an open fire or exposed to an external heat source.
- Stop using the device and all its accessories (especially the battery) if they have been dropped on the floor and show visible signs of damage or appear to be faulty.
- Do not short-circuit the battery under any circumstances, e.g. as a result of metal objects coming into contact with the battery terminals.
- Make sure that the power supply unit is not covered.

Risk of fire or explosion!

Charging non-rechargeable batteries can cause a fire or explosion!

- Only use the original Vorwerk battery that is compatible with your device.

Risk of fire or explosion!

If burning or readily ignitable substances should enter the interior of the device, this may cause fire or an explosion.

- Do not vacuum hot ash or burning cigarette ends.
- Do not vacuum explosive or readily inflammable substances.

Fire hazard!

The use of an incompatible charger can damage the battery and cause a fire.

- Only use the device with original Kobold accessories.

Fire hazard!

If water gets inside the battery, it could cause a fire.

- Never clean the battery with water, liquid cleaners or a wet cleaning cloth.
- Keep the battery away from water and other liquids.

Fire hazard!

The Kobold cordless handheld vacuum cleaner and its accessories are not compatible with Vorwerk mains-powered vacuum cleaners or their accessories.

- Never try to operate the cordless handheld vacuum cleaner or its accessories with the mains-powered vacuum cleaner series or their electrically powered accessories.

Fire hazard!

Coarse contaminants on the contacts could be conductive and result in a short circuit. A short circuit could cause a fire.

- Disconnect the charging device from the power and clean the charging plug with a dry or, if necessary, slightly damp cloth.

Fire hazard!

If the device or battery are accidentally triggered or activated when in transit, this could cause a build-up of heat, which could lead to a fire.

- Follow the instructions in the manual to ensure safe transportation.

Risk of choking!

Small parts may be accidentally swallowed and cause choking.

- Regularly check that the seam on the green nose of the cleaning cloth on the 2-in-1 wet and dry cleaning attachment is in good condition and replace it if the green nose is coming loose.
- Keep small parts such as fragrance chips out of the reach of children.

Risk of burns!

You may sustain burns from hot or boiling water.

- Do not pour hot or boiling water into the tank of the 2-in-1 wet and dry cleaning attachment.

**CAUTION****Risk of burns!**

If water enters the charging plug, it could heat up.

- Never clean the charging plug with water, liquid cleaners or a wet cleaning cloth.

Risk of injury due to negative pressure!

Vacuuming of skin or hair can cause injury.

- Do not vacuum any body parts or hair.
- Do not vacuum in the vicinity of children or pets.

Risk of injury from moving parts!

Moving parts (such as the rotating brushes or oscillating cloth holder) could cause injury.

- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.
- Never reach into the moving parts.
- Do not operate the electric upholstery brush without an attachment.
- Do not remove mattress-cleaning attachments while the electric upholstery brush is in operation.

Risk of injury from moving parts!

The suction shoe on the hard floor brush is pulled back to its original position by a spring and could injure you.

- Stay clear of the suction shoe as it springs back into place.
- Do not use force to turn the hard floor brush further than it should go, especially when the bristle plate has been removed.

Risk of falling and injury!

If you exert excessive pressure on the cordless handheld vacuum cleaner, you could lose your balance and fall.

- Always place the device and the accessory head on a level surface when in the standby position.
- Never use the device to support yourself.
- Never stand on the accessory heads.

Risk of injury if device is left running unattended!

If the device is left unattended, it could injure others.

- Before leaving the device unattended, switch it off using the on/off switch on the cordless handheld vacuum cleaner.

Risk of damage to skin and eyes!

Leaking batteries can cause injuries.

- Do not touch leaking batteries without skin and eye protection.
- Leaking batteries must not come into contact with the skin, eyes or mucous membranes.
- In case of accidental contact, wash your hands and flush the eyes or mucous membranes with clean water.
- If irritation persists, seek medical attention.
- Clothing and textiles that have come into contact with leaking battery fluid should be thoroughly washed immediately or disposed of.

Risk of injury due to sharp fragments of plastic!

Broken plastic can have sharp edges and you could injure yourself.

- Do not use the device if plastic components have been damaged due to being knocked or dropped.
- Protect yourself from fragments with sharp edges.

Risk of injury from debris flying out!

Debris that is being vacuumed could fly out and cause injury.

- Avoid abruptly placing the accessory head on loose, coarse debris (e.g. glass shards), especially at eye level.
- Avoid moving the accessory head sideways onto loose, coarse debris (e.g. glass shards).
- Switch off the accessory head before lifting it.
- Do not clean with the 2-in-1 wet and dry cleaning attachment at eye level (e.g. on stairs or landings).

Risk of injury!

The 2-in-1 wet and dry cleaning attachment is only suitable for use on floors. If the device is used on ceilings or walls, it may detach from the vacuum cleaner and fall onto the user.

- Only use the 2-in-1 wet and dry cleaning attachment to clean horizontal surfaces.
- Never use the 2-in-1 wet and dry cleaning attachment vertically or overhead.

Loss of suitability for allergy sufferers and risk of damage from improper use!

Unsuitable or damaged filter material will not retain fine, allergenic particles.

- Only use the original Kobold products that are intended to be used with this device.
- Do not reuse spent Kobold premium filter bags.
- Only use the device with an original Kobold premium filter bag installed.

! NOTICE

Risk of damage from improper use!

If the device is not in perfect working order, it could cause damage.

- Only use the original Vorwerk products that are intended to be used with this device.
- Do not operate the device if the device itself or the power cord are damaged or if the device is not fully assembled.

Risk of damage from improper use!

Improper use of the charger could damage the device.

- To charge the device, only use the original charger and/or charging unit and mains cable from Vorwerk that are designed to be used with this product.
- Only operate the charger and/or charging unit with the alternating current voltage and mains frequency stated on the type plate.

Risk of damage from improper use!

Improper use of the device may damage it.

- Do not block the air outlets during use under any circumstances. Keep the device free of contaminants that reduce airflow.

Risk of damage to the battery!

Incorrect use of the battery could damage it.

- Fully charge the device at least once a year in order to prevent deep discharge, which can shorten the life of the battery.

Risk of damage to the battery!

Extreme heat or cold shortens the charge time and/or can cause damage to the battery.

- Do not expose the device to fire, heat or direct sunlight.
- Do not leave the device near a heat source (oven, heater or hot radiator).
- Use and charge the device at temperatures between 5 °C and 35 °C.
- Store the device at temperatures between 5 °C and 35 °C.

Risk of damage to the device!

Moisture inside the device can damage it.

- Do not vacuum liquids or damp dirt.
- Do not vacuum damp doormats or carpets.
- Do not use the device in damp environments (in wet bathrooms or outdoor areas, etc.) or in places where there is a risk that the device could come into contact with liquids.
- Never pour water over the device or hold it under running water. Never immerse the device in water or other liquids.
- Do not store the device outdoors.
- Keep the device protected from moisture.

Risk of damage due to incorrect cleaning!

The device could get damaged if not cleaned correctly.

- Never clean the device with water, liquid cleaners or a wet cleaning cloth.
- Never wet-clean the roller brush. Use a dry or slightly damp cloth if necessary. The roller brush is not dishwasher safe or waterproof.
- Do not use abrasive cleaning pads, scouring agents or aggressive liquids such as benzene or acetone to clean the device.
- Do not use disinfectant to clean the device.

Risk of damage from improper use!

Damp in the filter area can damage the device.

- If the filter area becomes damp, dry it before using it again.
- Replace the premium filter bag and dry the motor protection filter.

Risk of damage from improper use!

A motor protection filter that has not dried properly can cause damage.

- If the motor protection filter is damp, let it dry out in a warm place for 24 hours before putting it back into the device.

Risk of damage from improper use!

If the device is not in good working order, it could cause damage.

- Only use the device with the motor protection filter installed.

Risk of damage from improper use!

The improper use of the device could cause damage to the floor.

- Avoid working with the electrically powered accessory heads in one specific spot for a prolonged period of time.
- To prevent damage to the floor, clean delicate hard floors and carpets with the automatic electric floor brush on a low roller-brush speed or with the roller brushes deactivated.
- Do not move the automatic electric floor brush diagonally or sideways across the floor, as this could permanently mark the floor.
- Avoid vacuuming up loose rugs and fringes or deactivate the roller brushes.
- Please refer to the cleaning and care information issued by the floor manufacturer.

Risk of material damage from incorrect storage!

The 2-in-1 wet and dry cleaning attachment could get damaged if the interior or exterior are exposed to moisture for a prolonged period.

- Never leave a wet cloth in the 2-in-1 wet and dry cleaning attachment when storing it.
- When storing the device, never leave residual fluid in the tank.
- Empty the tank fully after each use.

Material damage from fitting the tank incorrectly!

If the tank on the 2-in-1 wet and dry cleaning attachment is not handled correctly, it could cause damage.

- Avoid using force when inserting and removing the tank.

Risk of damage to the floor! **The improper use of the 2-in-1 wet and dry cleaning attachment could cause damage to the floor.**

- Never use the 2-in-1 wet and dry cleaning attachment without the cleaning cloth.
- Never work on the same spot for more than 10 seconds.
- Never leave the 2-in-1 wet and dry cleaning attachment standing on the floor with a wet cleaning cloth for more than 30 seconds as this could cause damage to delicate floors.
- Never dampen the cleaning cloth by hand. Moisture may only be applied to the cleaning cloth by the 2-in-1 wet and dry cleaning attachment. The cloth could otherwise become too wet.
- For delicate floors (such as floors which are not permanently sealed, e.g. oiled cork, oiled parquet, coated, oiled stoneware), try the device out in an inconspicuous area first to prevent damage to the floor.
- If floors that are extremely sensitive to moisture become too wet, wipe dry using a dry Parquet or Dry cleaning cloth and the vacuum cleaner.
- If the 2-in-1 wet and dry cleaning attachment gets jammed or caught on something, it should be switched off immediately in order to prevent damage.

Material damage due to incorrect cleaning agents! **The improper use of cleaning agents when operating the 2-in-1 wet and dry cleaning attachment can cause damage.**

- Only use original Kobold cleaning agents.
- Never use acid cleaning agents (e.g. vinegar-based cleaner) or highly alkaline cleaning agents (e.g. chlorine bleaching).

Damage to the floor from sharp-edged objects! **Sharp fragments underneath the cleaning cloth could cause damage to the floor.**

- Before switching on the device, make sure that there are no small stones, granulates (e.g. cat litter) or other pointed or sharp-edged objects under the cleaning cloth.

Risk of damage from applying moisture incorrectly! **Adding moisture to the dry cleaning cloth could cause damage to the device.**

- Do not apply moisture when using the Dry cleaning cloth.

Material damage from fitting the cloth holder incorrectly!

If the cloth holder on the 2-in-1 wet and dry cleaning attachment is not handled correctly, it could cause damage.

- When attaching the cleaning cloth to the cloth holder, always ensure that the cloth is fastened evenly. Make sure that you do not attach the cleaning cloth to the cloth holder at an angle.
- Avoid using force when inserting and removing the cloth holder.

Risk of damage from using Lavenia on unsuitable surfaces!

If Lavenia mattress cleaning powder is used incorrectly, it could cause damage.

- Test the colour fastness of the mattress against Lavenia in an inconspicuous spot before application.

Risk of damage to mattresses!

If the mattress cleaning set is used incorrectly, it could damage your mattresses.

- Avoid working with the device in one specific spot for a prolonged period of time (max. 5 seconds).
- Do not vacuum mattresses with the suction shoe of the electric upholstery brush. Use only the mattress deep cleaning accessory to avoid damage to mattresses.
- Use Lavenia and the mattress cleaning set only on mattresses. The mattress cleaning set is not suitable for use on other upholstery fabrics or furniture, and may damage delicate materials.
- Use the mattress freshening accessory with the corresponding nubbed disc exclusively for mattress cleaning.
- Do not press the device firmly onto the mattress. Doing so could cause damage to your mattress and the device.

Risk of damage from improper use!

Unsuitable carpet cleaning agents can damage the device.

- Only use Kobosan Active for cleaning carpets, and only vacuum it up once it is completely dry.

Risk of damage from improper use!


Using the nozzle set (Kobold accessories) incorrectly could damage surfaces.

- Do not use nozzles from the nozzle set on smooth or polished surfaces.

4.2 Classification of safety warning messages

The safety warning messages in this manual are highlighted by safety symbols and signal words. The symbol and signal word indicate the severity of the potential hazard.





Classification of safety warning messages The safety warning messages that precede each action are shown as follows:

WARNING	
	Type and source of hazard Explanation of type and source of hazard/consequences <ul style="list-style-type: none">Measures to prevent hazard

Meaning of signal words

WARNING	Risk of death or serious injury if hazard is not avoided.
CAUTION	Risk of minor injury if hazard is not avoided.
NOTICE	Material damage if hazard is not avoided.

Meaning of safety symbols

	Safety warning message indicating the severity of the potential hazard
	Reference to material damage
	Device has an earth connection for functional reasons
	Device of protection class II

4.3 Obligations of the User

To ensure that your appliance and Vorwerk accessory operate correctly, please follow the guidelines below:

1. Please read the instruction manual and all accompanying documents carefully.
2. Store the manual near the appliance.

3. Ensure that any damage to the appliance is repaired by the manufacturer without delay.


5 Suitability for different types of floors

Carpet type	Kobold EB7	Kobold SP7	Kobold HD7
Loop pile carpeting, Velour carpeting	++	-	-
Berber carpeting, deep-pile carpeting, light, loose carpets, silk carpeting, sisal carpeting	+		
Fur	-		
Flokati	+*		
Loosely woven carpets	+*		
Carpets with long interwoven fibres (Saxony)	+*		
Yoga mats	+*		
Hard floor type			
Sealed/varnished wooden floors (floorboards, parquet)	++	++	++
Oiled/waxed wooden floors	+	++	+
Unsealed/untreated wooden floors	-	- **	+
Sealed cork floors	++	++	++
Oiled/waxed cork floors	+	- **	+
Unsealed/untreated cork floors	-	- **	+
Laminate	++	++	++
Elastic flooring (PVC, cushion vinyl, linoleum)	+	++	++
Stone floors (marble, granite, Jura limestone, artificial stone)	+	++	+
Porous/delicate natural stone (slate, clinker tiles)	-	+	+
Clay floors (terracotta, clinker, brick clay tiles)	+	++	+
Ceramic glazed tiles and fine stoneware	++	++	++
Untreated tiled floors	-	- **	+
Rough concrete flooring (washed concrete)	-	-	+

++	excellent suitability	*	only with the Kobold EB7 in deactivated brush mode
+	very good suitability	**	dry cleaning only
-	not suitable		

6 Kobold VK7 cordless handheld vacuum cleaner

6.1 Product overview




Overview of the Kobold VK7 cordless handheld vacuum cleaner

1 +/- buttons	7 Battery with display
2 On/off switch	8 Filter cover
3 Boost button	9 Handle lock for rotating handle
4 Release button for rotating handle	10 Charging connector
5 Remote unlocking for accessory heads	11 Attachment socket
6 Release lever for battery/filter cover	

6.2 Getting started

6.2.1 Opening and closing the rotating handle



The rotating handle on the cordless handheld vacuum cleaner is folded down on delivery.

1. To open the rotating handle, press the release button (1) on the pivot of the cordless handheld vacuum cleaner.
2. Now turn the rotating handle clockwise (2) until you hear a click.
3. To fold the rotating handle in again, press the release button (1) on the pivot of the cordless handheld vacuum cleaner.
4. Now turn the rotating handle anticlockwise (3) until you hear a click.
⇒ *The rotating handle clicks into place in the handle lock on the front of the cordless handheld vacuum cleaner (4).*

With the handle folded down, the cordless handheld vacuum cleaner is easy to carry or use with the [shoulder strap](#) [▶ 89], making it ideal for cleaning areas above floor level, see [Cleaning upholstery](#) [▶ 74] or [Cleaning mattresses](#) [▶ 74] or [Nozzle set](#) [▶ 87].


What's more, it also takes up less space when [stored](#) [▶ 33] or [charging](#) [▶ 27].

6.2.2 Attaching and unlocking the accessory head

Attaching the accessory head


The attachment process is the same for all the accessory heads:

1. Connect the attachment socket on the cordless handheld vacuum cleaner (1) to the joint connector on the accessory head (2).
2. Make sure you hear the attachment socket click into the joint connector.



Unlocking the accessory head

1. To disconnect the cordless handheld vacuum cleaner from the accessory head again, first put the cordless handheld vacuum cleaner on the floor.
2. Release the accessory head by pulling the remote unlocking catch (3) (at the top on the rotating handle) upwards.
⇒ *Once unlocked, you can remove the cordless handheld vacuum cleaner from the accessory head.*



You can also put your foot on the accessory head as you detach the cordless handheld vacuum cleaner from it. This makes it easier to remove the cordless handheld vacuum cleaner from the accessory head.


6.2.3 Standby position

You can either use the cordless handheld vacuum cleaner together with an accessory head on the power setting (2) or set it to standby (1).

The standby position is used for storing your cordless handheld vacuum cleaner when you are not using it. You can also 'park' it in this position if you want to take a short break while cleaning. In the standby position, the device stands upright and firmly on the floor.

Setting and releasing the standby position

The process described here applies only to the automatic electric floor brush and the hard floor brush. For instructions on setting and releasing the standby position on the 2-in-1 wet and dry cleaning attachment, see [Standby position](#) [▶ 55].



Putting the device into standby position

You can only put the cordless handheld vacuum cleaner into standby position when it is centred.

- Push the cordless handheld vacuum cleaner forwards (1).
⇒ *The cordless handheld vacuum cleaner clicks into the standby position.*

Taking the device out of standby position

- Hold the accessory head firmly in place with your foot and tilt the handle of the cordless handheld vacuum cleaner back until you hear it disengage from the standby position (2).
⇒ *The cordless handheld vacuum cleaner is now in the power setting.*

6.3 Charging

6.3.1 Before charging for the first time

1. Remove the protective film from the battery.
2. [Insert the battery](#) [▶ 39].


On rare occasions, additional graphics may briefly appear on the display directly after the protective films have been removed. These will disappear on their own after a few moments.

6.3.2 Charging with different chargers

You can charge the cordless handheld vacuum cleaner with the [single charger](#) [▶ 28] or the [dual battery charger](#) [▶ 84].

You cannot use the cordless handheld vacuum cleaner while it is charging.

6.3.3 Charging with the single charger




1. Put the cordless handheld vacuum cleaner into the **standby position** [▶ 26].
2. Note the prescribed mains voltage of 220-240 V AC.
3. Connect the single charger to the power supply.
4. Insert the charging connector (2) into the socket on the cordless handheld vacuum cleaner (1) and slide it upwards.
⇒ *The display lights up, charging is active.*

For instructions on charging the cordless handheld vacuum cleaner with the dual battery charger, see **Charging with the dual battery charger** [▶ 84].

6.3.4 Charging a separate battery with the single charger

You can also charge a battery separately. This is useful if, for example, you want to work with an additional battery.




1. Place the charging adapter (1) on a clean, solid and even surface so that it cannot slip.
2. Insert the charging connector (2) into the charging adapter (1).
3. Place the cable in the guide provided.
4. Note the prescribed mains voltage of 220-240 V AC.
5. Connect the single charger to the power supply.
6. Insert the separate battery (3) into the charging adapter.
⇒ *The display lights up, charging is active.*

6.4 Display

6.4.1 Charging display

As soon as you start charging the cordless handheld vacuum cleaner, the display switches to the charging display.




-
- | | |
|---|--|
| 1 | Display |
| 2 | Charge level in per cent
Here 90%: battery is 90 per cent charged |
| 3 | The flashing dot indicates that the battery is charging |
-

When the battery is fully charged, a smiley appears on the display. After 2 minutes, the display goes out.

Charging time is approx. 2 hours, depending on the ambient conditions.


6.4.2 System and power display

Power level and battery charge level



-
- | | |
|-----------|---|
| 1 | Power display, or moisture setting for the 2-in-1 wet and dry cleaning attachment [▶ 59]
For further information on setting the suction power level, see Selecting the power level [▶ 31]. |
| 2 | Battery charge level in per cent
For further information on the battery running time, see Battery running times [▶ 33]. |
| <i>Er</i> | Error codes
For further information and guidance, see Troubleshooting [▶ 90]. |
-


The indicators on the display are approximate values.



System display

- | | |
|---|--|
| 1 | Filter indicator, see Inserting and changing the premium filter bag [▶ 37] . |
| 2 | Warning triangle, see Troubleshooting [▶ 90] . |
| 3 | Bluetooth®, see Smart Home: Bluetooth® and MyKobold app [▶ 32] . |
| 4 | Droplet, see Removing, filling and inserting the tank [▶ 57] . |

6.5 Operation



- | | |
|---|---|
| 1 | On/off switch |
| 2 | +/- buttons, for changing the power or moisture setting |
| 3 | Boost button |
| 4 | Display |

Note on the position of the buttons

The orientation of the +/- buttons remains the same with the handle open or closed.

6.5.1 Switching on and off

The cordless handheld vacuum cleaner must be **fully charged** [▶ 27] before first use.

1. Always unplug the charging connector from the cordless handheld vacuum cleaner before switching it on. Otherwise the cordless handheld vacuum cleaner will not switch on.
2. Switch the cordless handheld vacuum cleaner on at the on/off switch (1).
 - ⇒ *The display switches on. The power or moisture level and battery charge level (in per cent) are displayed.*


3. Switch the cordless handheld vacuum cleaner off at the on/off switch f(1).
 - ⇒ *The display goes out. If Bluetooth® is activated, it will remain active for another 3 minutes or so. The Bluetooth® symbol will then also go out.*

6.5.2 Selecting the power level

- The power level or moisture level is selected using the +/- buttons (1).

The different power levels and moisture levels are specially designed for specific uses:

- Kobold EB7 automatic electric floor brush [▶ 46]
- Kobold SP7 2-in-1 wet and dry cleaning attachment [▶ 59]
- Kobold HD7 hard floor brush [▶ 68]
- Kobold PB7 electric upholstery brush with Kobold MP7/MR7 mattress cleaning set [▶ 73]




6.5.3 Boost button

By pressing the boost button (1) on the back of the handle, you can switch the cordless handheld vacuum cleaner to maximum power. The power display flashes in boost mode (2). The boost mode is useful if, for example, you want to clean a particularly dirty section of floor.

For more information on the boost mode for each accessory head, see:

- Kobold EB7 automatic electric floor brush [▶ 46]
- Kobold SP7 2-in-1 wet and dry cleaning attachment [▶ 59]
- Kobold HD7 hard floor brush [▶ 68]
- Kobold PB7 electric upholstery brush with Kobold MP7/MR7 mattress cleaning set [▶ 73]



6.6 Smart Home: Bluetooth® and MyKobold app

The MyKobold app offers many useful features, allowing you to customise the way you use your cordless handheld vacuum cleaner. The app also contains information on the devices as well as helpful tips for troubleshooting.

6.6.1 Installing and pairing the MyKobold app



1. Download the MyKobold app from the Apple App Store or Google Play Store and install it on your smartphone or tablet. You can find the app under the name *MyKobold*.



2. Launch the app and follow the instructions to connect your cordless handheld vacuum cleaner to the MyKobold app and to enable Bluetooth®.

Bluetooth® The screen and charging display function differently if Bluetooth® is enabled on the cordless handheld vacuum cleaner.

In standby, the screen displays the Bluetooth® symbol for the first three minutes instead of being completely black.

Note In order to use your cordless handheld vacuum cleaner with the MyKobold app, please take note of the following:

- An internet connection is required.
- To use all the features on the MyKobold app in conjunction with the cordless handheld vacuum cleaner, you need to set up a free user account with your e-mail address.
- The Kobold Robot app is compatible with all current smartphones and tablets with iOS or Android operating systems. For information on currently supported devices, see the MyKobold app page in the Google Play Store or the Apple App Store.

6.7 Battery running times

The running time for the cordless handheld vacuum cleaner differs depending on the power levels and moisture levels selected.

Mode	Kobold EB7 Hard Floor	Kobold EB7 Carpet	Kobold HD7	Kobold SP7	Kobold PB7
Power level 1	36 min	28 min (60 min with roller brushes deactivated)	60 min	23 min	140 min (Lavenia mode)
Power level 2	24 min	21 min	34 min		30 min
Power level 3	11 min	not recommended	17 min		16 min
Power level 4	not recommended	9 min	11 min		10 min
Boost	8 min	8 min	9 min	10 min	9 min

Note The stated operating times are typical operating times. They have been determined using a battery in new condition and at a room temperature of 21 °C. Actual operating times may differ. The operating times given are approximate values that depend on the type of use and the ambient conditions. Low and high temperatures can, for example, shorten the operating time of the battery.

The battery ages during the period of use, and the operating time of the battery diminishes during this time. The operating times have been determined using a fully charged battery.

In order to preserve the battery, it will only start recharging when it has fallen below a certain charge threshold.

6.8 Storing the cordless handheld vacuum cleaner

1. When you are not using your cordless handheld vacuum cleaner, switch it off and store it carefully.
2. If you are going to store your cordless handheld vacuum cleaner for a long period, you should remove the battery from the device, see [Removing or inserting the battery](#) [► 39].
3. Unused batteries should be charged fully at least once a year.

6.9 Transportation

WARNING



Fire hazard!

If the device or battery are accidentally triggered or activated when in transit, this could cause a build-up of heat, which could lead to a fire.

- Follow the instructions in the manual to ensure safe transportation.

The device contains lithium-ion batteries, which are subject to dangerous goods regulations. You can transport the batteries by road (e.g. in your vehicle) without having to meet further requirements. Information on the number of cells and energy of the cells or battery can be found on the battery's data plate.

The device is delivered in transport mode and is therefore already secured against activation. This means that it can be safely shipped in the original packaging without the removal of the battery. Nevertheless, please observe points 1, 5 and 6. If you have started operating the device, transport mode is deactivated.

If the batteries are shipped by a third party (e.g. air freight or courier), you must comply with special requirements with regard to packaging and labelling.

1. Only ship batteries if the battery housing is undamaged. If you are in any doubt as to whether the battery is undamaged, do not ship the battery. If in doubt, consult a dangerous goods expert.
2. If shipping by air freight, the battery must have a charge of 30% or less.
3. If possible, set the battery to **transport mode** [▶ 35] using the cordless handheld vacuum cleaner, as it must not switch on when in transit.
4. If this is not possible, **remove the battery** [▶ 39], cover exposed contacts and pack the battery separately from the device in such a way that it cannot move inside the packaging. To obtain suitable original packaging, please contact customer service.
5. Always check with your shipping provider how to pack and label the package. This will depend on whether you are shipping the battery on its own or with the device, and whether the package is to be transported by air.
6. Ensure that you also comply with any additional national and international regulations.

6.9.1 Setting the device to transport mode

If you are going to transport your cordless handheld vacuum cleaner, set it first to transport mode. This ensures that it does not switch on accidentally.

You can only ship the cordless handheld vacuum cleaner with the battery installed if the battery is in transport mode.

1. Make sure that the cordless handheld vacuum cleaner is not connected to the charger and is switched off.
2. Press and hold the on/off switch and one of the two +/- buttons at the same time for 2 seconds until the battery status is shown on the display.
3. Press and hold the on/off switch and boost button at the same time for 6 seconds until all the elements on the display light up.
4. After no more than 1 second, press and hold the on/off switch and boost button at the same time **again** for 6 seconds until all the elements on the display are flashing.
5. After no more than 1 second, press and hold the on/off switch and boost button at the same time **again** for 6 seconds until an inverted *JL* appears on the display.

⇒ *The battery is now in transport mode and may be shipped.*

You can deactivate transport mode again by **charging** [▶ 27] the cordless handheld vacuum cleaner.



6.10 Factory reset

Important! You can reset the cordless handheld vacuum cleaner to the factory settings. All settings that have been previously saved will be lost.

1. Set your cordless handheld vacuum cleaner, in combination with the automatic electric floor brush or the 2-in-1 wet and dry cleaning attachment, to standby.
2. Then press the on/off switch.
⇒ *The display will show the battery charge level in per cent.*
3. Press and hold both +/- buttons at the same time for at least 6 seconds.
⇒ *The cordless handheld vacuum cleaner is reset to the factory settings.*

6.11 Maintenance

CAUTION



Risk of injury from moving parts!

You could injure yourself on moving parts.

- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.
- Never reach into the moving parts.

6.11.1 Spare parts and consumables


We recommend you take advantage of our reorder options for original care products and original consumables in good time. For more details on the reorder options, see [Customer Service \[▶ 104\]](#) or the [MyKobold app \[▶ 32\]](#).


6.11.2 Opening and closing the filter cover

If you need to [change the premium filter bag \[▶ 37\]](#) or [remove the battery \[▶ 39\]](#), you must first open the filter cover.

Opening the filter cover

1. The cordless handheld vacuum cleaner must be switched off. Before opening the filter cover, carefully lay the cordless handheld vacuum cleaner down or set it to [standby position \[▶ 26\]](#).
2. Operate the release lever (1) to remove the filter cover (2).
3. Pull the filter cover upwards to remove it (3), and put it to one side.





Closing the filter cover

1. Insert the tab at the bottom of the filter cover (4) into the cordless handheld vacuum cleaner (5).
2. Applying only slight pressure, close the filter cover until you hear it click into place.
3. Make sure that the **motor protection filter is correctly inserted** [▶ 39].
4. When putting the filter cover back on, make sure that the premium filter bag does not get caught between the cover and the seal.
5. Do not use force if it is difficult to close the filter cover. Make sure that the premium filter bag is correctly inserted.

Make sure that the **premium filter bag is correctly inserted in the cordless handheld vacuum cleaner** [▶ 37]. For safety reasons, the cordless handheld vacuum cleaner will not close if the premium filter bag is missing or incorrectly installed.

6.11.3 Inserting and changing the premium filter bag

CAUTION



Loss of suitability for allergy sufferers and risk of damage from improper use!

Unsuitable or damaged filter material will not retain fine, allergenic particles.

- Only use the original Kobold products that are intended to be used with this device.
- Do not reuse spent Kobold premium filter bags.
- Only use the device with an original Kobold premium filter bag installed.




If the *filter change* symbol is permanently lit, the premium filter bag is almost full. If the *filter change* symbol is flashing, the premium filter bag is full.

The frequency with which the *filter change* symbol recommends the replacement of the premium filter bag depends on what is vacuumed. If a large quantity of fine dust has been vacuumed, the pores of the premium filter bag will clog more quickly. This means that it may be necessary to change the premium filter bag even if it


does not yet appear to be completely full. However, if coarse dirt is vacuumed, it may only be necessary to change the premium filter bag when it is full to capacity.

Removing the premium filter bag




1. The cordless handheld vacuum cleaner must be switched off. Before changing the filter bag, carefully lay the cordless handheld vacuum cleaner down or set it to **standby position** [▶ 26].
2. **Open and remove the filter cover** [▶ 36].
3. Fold the closure flap (2) at the base of the premium filter bag forwards slightly to make it easier to remove the premium filter bag (1).
4. Remove the premium filter bag (1) by pulling it out of its holder by the closure flap (2).
5. Close the hygiene seal by folding the closure flap over (2) and inserting it into the opening (3) on the premium filter bag.

Inserting a premium filter bag



1. Insert a new premium filter bag (1), with its retaining plate inserted at an angle (3), into the filter compartment. The closure flap (2) is in a hinged position and resting against the filter bag.
2. Tilt the premium filter bag onto the suction socket (4).
3. Make sure that the premium filter bag sits completely flush (5) and is fully inside the filter compartment. Make sure that the premium filter bag does not hang over the edge of the filter compartment.

6.11.4 Removing or inserting the battery



1. The cordless handheld vacuum cleaner must be switched off. Before removing or changing the battery, carefully lay the cordless handheld vacuum cleaner down or set it to **standby position** [▶ 26].
2. **Open and remove the filter cover** [▶ 36].
3. To remove the battery, press the battery locking lever (1) while pulling the release lever (2) upwards.
4. Now pull the battery out of its guide rail in the filter cover.
5. Insert the battery (3) by sliding it all the way into its holder.
6. **Put the filter cover back on** [▶ 36].

6.11.5 Removing, cleaning and inserting the motor protection filter


NOTICE



Risk of damage from improper use!

A motor protection filter that has not dried properly can cause damage.

- If the motor protection filter is damp, let it dry out in a warm place for 24 hours before putting it back into the device.



The motor protection filter (1) protects your cordless handheld vacuum cleaner from contaminants. To ensure the long service life of your cordless handheld vacuum cleaner, it is important to carry out visual checks and maintenance on the motor protection filter at regular intervals. The motor protection filter can be cleaned as many times as necessary. It must only be replaced if the premium filter bag has been damaged or if the motor protection filter is extremely dirty or gummed up.

Removing, cleaning and inserting the motor protection filter


1. Take hold of the motor protection filter in the middle (2) and pull it upwards to remove it.
2. Clean the motor protection filter on both sides.
3. If the motor protection filter is damaged or is extremely dirty, insert a new one.
4. To reinsert the motor protection filter, slide it back in on the guide rails (3).

Cleaning the motor protection filter



Option A

You can clean the motor protection filter by vacuuming it on both sides with another vacuum cleaner.



Option B

Alternatively, you can rinse the motor protection filter under cold running water. Allow the motor protection filter to dry out completely in a warm place for at least 24 hours before putting it back into the cordless handheld vacuum cleaner.

6.11.6 Replacing fragrance chips


WARNING



Risk of choking!

Small parts may be accidentally swallowed and cause choking.

- Keep small parts such as fragrance chips out of the reach of children.



1. Remove the motor protection filter [▶ 39] (1).
2. Remove the old fragrance chip (2) by sliding it out of the fragrance-chip holder from underneath (3).
3. Slide the new fragrance chip (2) into the fragrance-chip holder from above (4).
4. Put the motor protection filter back in [▶ 39].


6.12 Technical Data

6.12.1 Cordless Handheld Vacuum Cleaner

Kobold VK7 cordless handheld vacuum cleaner

Safety symbols



Housing	High-quality, recyclable, thermoformed plastic			
Motor	Maintenance-free BLDC motor, with max. 95,000 rpm			
Nominal output	400 W in Boost mode			
Voltage	28.8 V or 29.6 V (depending on cell type)			
Charger input voltage	220-240 V alternating current, 50/60 Hertz (automatic adjustment)			
Max. negative pressure	max. negative pressure 112 hPA (level 4 – 89,000 rpm)			
Max. volume flow	max. volume flow 27 l/s (empty bag without accessory head) (level 4 – 89,000 rpm)			
Premium filter bag volume	0.8 l			
Weight	approx. 2.3 kg (cordless handheld vacuum cleaner without accessory head)			
Dimensions	Height: approx. 22 cm (approx. 21 cm with the rotating handle closed) Width: approx. 14 cm Length: approx. 55 cm (approx. 93 cm with the rotating handle open)			
Sound power level	77 dB(A) re 1 pW (for Kobold VK7 cordless handheld vacuum cleaner with Kobold EB7 automatic electric floor brush on carpet)			
Charger	 : For the connection of the electrical appliances to the mains power, a separate, designated power supply unit, e.g. the single charger or dual battery charger, is required.			
Battery	Rechargeable lithium-ion battery Type designation: Battery Pack ...			
Battery charge time	approx. 2 hours			
Information on connectivity	2.4 GHz	2400 - 2483.5 MHz	< 10 dBm	Bluetooth® 5.1 Low Energy
	The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. Any use of these word marks and logos by Vorwerk Elektrowerke GmbH & Co. KG is under licence.			

6.12.2 Single charger

Kobold SC7 single charger

Name or trade mark of the manufacturer, company registration number and address	Vorwerk Elektrowerke GmbH & Co. KG HRB 7852 Mühlenweg 17-37 42270 Wuppertal, Germany
---	---

Type designation	SC7 ...
------------------	---------

Input voltage	220-240V AC
---------------	-------------

Input AC frequency	50/60 Hz (automatic adjustment)
--------------------	---------------------------------

Output voltage	37V DC
----------------	--------

Output current	1.3 A
----------------	-------

Output power	48.1 W
--------------	--------

Average active efficiency	> 87.77 %
---------------------------	-----------

Efficiency at low load (10 %)	> 78 %
-------------------------------	--------


Power consumption at zero load	< 100 mW
--------------------------------	----------

Safety symbols	
----------------	--



7 Kobold EB7 automatic electric floor brush

7.1 Product overview



Overview of the Kobold EB7 automatic electric floor brush

1 Pivot	4 Boost cap
2 Side caps (left and right)	5 Roller brushes
3 Front and side sealing lips	6 Inspection flap

7.2 Suitability for different types of floors


Carpet type	Kobold EB7
Loop pile carpeting, Velour carpeting	++
Berber carpeting, deep-pile carpeting, light, loose carpets, silk carpeting, sisal carpeting	+
Fur	-
Flokati	+*
Loosely woven carpets	+*
Carpets with long interwoven fibres (Saxony)	+*
Yoga mats	+*
Hard floor type	
Sealed/varnished wooden floors (floorboards, parquet)	++
Oiled/waxed wooden floors	+
Unsealed/untreated wooden floors	-
Sealed cork floors	++
Oiled/waxed cork floors	+
Unsealed/untreated cork floors	-
Laminate	++
Elastic flooring (PVC, cushion vinyl, linoleum)	+
Stone floors (marble, granite, Jura limestone, artificial stone)	+
Porous/delicate natural stone (slate, clinker tiles)	-
Clay floors (terracotta, clinker, brick clay tiles)	+
Ceramic glazed tiles and fine stoneware	++
Untreated tiled floors	-
Rough concrete flooring (washed concrete)	-

- ++ excellent suitability
- + very good suitability
- not suitable
- * only with brush mode deactivated


7.3 Operation

7.3.1 Selecting the power level

- The power level is selected using the +/- buttons (1).



7.3.2 Overview of power levels and brush mode




Display	Power level	Suction power Kobold VK7	Mode Kobold EB7
1	Level 1 <i>min</i> minimum power with automatic adjustment to floor type	automatic minimum power range dependent on floor type	automatic speed dependent on floor type
2	Level 2 <i>med</i> medium power with automatic adjustment to floor type	automatic medium power range dependent on floor type	automatic speed dependent on floor type
3	Level 3 <i>hard floor max</i> maximum power for hard floors	maximum power	low speed
4	Level 4 <i>carpet max</i> maximum power for carpets	maximum power	maximum speed
5	Boost [▶ 47]	Briefly operates on maximum power	Boost mode
	Deactivating the roller brushes	The roller brushes can be deactivated on any power setting except boost mode.	Roller brushes deactivated

Display	Power level	Suction power Kobold VK7	Mode Kobold EB7
	<p>The roller brushes on the automatic electric floor brush are deactivated by pressing one of the +/- buttons for 2 seconds.</p> <p>Pressing the +/- button again changes the suction level and starts up the roller brushes again.</p>	<p>Deactivating the roller brushes significantly increases the battery running time [▶ 33].</p>	

7.3.3 Activating the boost cap

In boost mode, you can vacuum large, coarse particles.


- Hold down the boost button (1). The boost cap on the automatic electric floor brush (2) stays open for as long as you hold down this button to vacuum coarse dirt (3) even more effectively.



7.3.4 Personalised cleaning setting

You can configure **power level 2 on the automatic electric floor brush** [▶ 46] for a particular type of floor in the **MyKobold app** [▶ 32]. This means that the speed of the roller brushes and the suction power of the cordless handheld vacuum cleaner will be set according to the information you have entered and saved in the **MyKobold app** [▶ 32]. On this power level, the second arc on the display lights up.

1. **Connect the automatic electric floor brush to the cordless handheld vacuum cleaner** [▶ 26].
2. Follow the further instructions in the app.



7.3.5 Standby position


If you set the cordless handheld vacuum cleaner to **standby** [▶ 26] when it is switched on, the **system and power display** [▶ 29] will change to the battery display. If you do not use the cordless handheld vacuum cleaner for more than 3 minutes, it will automatically switch off.

7.3.6 Vacuuming

1. Before using the automatic electric floor brush, make sure that the device is **suitable for your floor** [▶ 45].
2. To vacuum efficiently, move the device back and forth in an even motion.

7.3.7 Instructions for use

1. Select the most appropriate **power level** [▶ 46] for very dirty floors and carpets.
2. Always move the device evenly back and forth.
3. Never let the device work in one place for a longer period as this could cause damage to the floor.
4. The rotating roller brushes can mechanically work on and comb fringes on rugs. Simply pull the automatic electric floor brush backwards over fringes, away from the rug.
5. Vacuum rug edges parallel to the edge.



7.4 Maintenance

CAUTION



Risk of injury from moving parts!


Moving parts (such as the rotating brushes) could cause injury.

- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.
- Never reach into the moving parts.

7.4.1 Spare parts and consumables


We recommend you take advantage of our reorder options for original care products and original consumables in good time. For more details on the reorder options, see [Customer Service \[▶ 104\]](#) or the [MyKobold app \[▶ 32\]](#).

7.4.2 Checking and cleaning



1. Check the underside of the automatic electric floor brush every once in a while to prevent damage to the device and floor.
2. Perform visual inspections from time to time in order to detect defects or very dirty areas.
3. Remove any dirt. Remove any hairs or fibres that are coiled around the small rollers at the front and check that the rollers rotate freely.
4. If threads or hairs have become coiled around the roller brushes, you can simply run a pair of scissors along the groove on the roller brush to cut and remove them.
5. If a substantial amount of debris is coiled around the brushes, [remove the roller brushes \[▶ 50\]](#) to clear threads, hairs and fibres from the metal shaft.


7.4.3 Changing the roller brushes



1. Turn the side caps upwards in a rotational motion (1).
2. Pull the roller brushes (2) and (3) away from the drive shaft.
3. Clear away any dirt from the drive shafts (4). Also check the inner central section.
4. **Clean** [▶ 49] any dirt from the roller brushes (2) and (3).
5. Insert the roller brush with the green end (2) on the left-hand side and the roller brush with grey end (3) on the right-hand side.
6. Press the roller brushes onto the drive shaft with a slight rotation until they are fully inserted.
7. Check that the roller brushes are correctly positioned on the drive shaft.
8. Fold the side caps (1) back down and lock them into place.

Attaching the side caps


The side cap can come away from the automatic electric floor brush.



1. Click the side cap (1) back into place on the automatic electric floor brush.
2. Fold the side caps back down (2) and lock them into place.

7.4.4 Changing the rear sealing lip

If the rear sealing lip is defective, it can be replaced.



1. Place the automatic electric floor brush upside down on a soft surface.
2. Make sure that the pivot is facing towards you.
3. Pull the rear sealing lip (1) sideways to remove it.
4. To fit the new sealing lip, insert it into the holder from the side.

7.5 Technical Data

Kobold EB7 automatic electric floor brush


Safety symbols



Housing	High-quality, recyclable, thermoformed plastic
Motor	Maintenance-free DC motor at approx. 9400 rpm
Nominal output	80 W
Voltage	28.8 V
Weight	approx. 1.65 kg
Roller brushes	2 replaceable rotating brushes
Working width	approx. 25 cm
Rotational speed of the brush	4700 rpm or 1550 rpm or 0 rpm
Dimensions	approx. 25 cm x 44 cm x 8 cm
Sound power level	77 dB(A) re 1 pW (with Kobold VK7 cordless handheld vacuum cleaner on carpet) 80 dB(A) re 1 pW (with Kobold VK7 cordless handheld vacuum cleaner on a hard floor)

8 Kobold SP7 2-in-1 wet and dry cleaning attachment

8.1 Product overview



Overview of the Kobold SP7 2-in-1 wet and dry cleaning attachment

1	Pivot	9	Cloth holder plate
2	Tank installed	10	Rear sealing lip frame
3	Pedal for releasing the cloth holder frame	11	Tank cap with dosing aid
4	Inspection flap	12	Tank
5	Cleaning cloth on cloth holder in the device	13	Tank release mechanism
6	Front and rear suction openings	14	MF600 cleaning cloths (Universal, Universal Soft, Parquet, Dry)
7	Front sealing lip frame	15	Koboclean (Universal, Parquet, Wood Floor Soap)*
8	Cloth holder		

Availability varies depending on the country

8.2 Suitability of the cleaning cloths for diverse floor types

Hard floor type	Universal	Universal Soft	Parquet	Dry
Sealed/varnished wooden floors (floorboards, parquet)	+	+	++	++*
Oiled/waxed wooden floors	++*	+	++	++*
Unsealed/untreated wooden floors	-	-	-	+
Sealed cork floors	+	+	++	++*
Oiled/waxed cork floors	-	-	-	+
Unsealed/untreated cork floors	-	-	-	+
Laminate	+	++	+	++
Elastic flooring (PVC, cushion vinyl, linoleum)	++	++	-	++
Stone floors (marble, granite, Jura limestone, artificial stone)	++	++**	-	++
Porous/delicate natural stone (slate, clinker tiles)	+	++	-	++
Clay floors (terracotta, clinker, brick clay tiles)	++**	++**	-	++
Ceramic glazed tiles and fine stoneware	++	++**	-	++
Untreated tiled floors	-	-	-	+
Rough concrete flooring (washed concrete)			excluded	
Textile flooring			excluded	

++ excellent suitability

+ very good suitability

- not suitable

* Cloths contain microfibres; follow the manufacturer's cleaning and care instructions.

** Increased wear is possible on rough floors.

8.3 Cleaning cloths

The Kobold MF600 cleaning cloths have been specially developed for the 2-in-1 wet and dry cleaning attachment. The cleaning cloth is available in the following four types:



Kobold MF600 Universal

Is particularly suitable for all surfaces that can be wet-cleaned (e.g. tiles, PVC, also suitable for textured surfaces).



Kobold MF600 Universal Soft

Is particularly suitable for use on porous or shiny floors that can be wet-cleaned (e.g. marble, granite, artificial stone, laminate).



Kobold MF600 Parquet

Is particularly suitable for wet-cleaning wooden floors (e.g. parquet, sealed cork flooring).



Kobold MF600 Dry

Is particularly suitable for dry-cleaning hard floors.

Type and number of cleaning clothes included may vary.

For best results, we recommend washing the cleaning cloths in the washing machine before first use and after every subsequent use, see [Washing cleaning cloths](#) [▶ 63].

8.4 Koboclean

The cleaning concentrates are suitable for cleaning various types of hard floors.



Koboclean Universal

For use on all sealed surfaces that can be wiped with a damp cloth (e.g. tiles, PVC).



Koboclean Parquet

Specially developed for cleaning sealed wooden surfaces that can be wiped with a damp cloth (e.g. cork, parquet, laminate).



Koboclean Wood Floor Soap

Specially developed for cleaning and maintaining wooden floors with an oil, wax or soap finish that can be wiped with a damp cloth.

The cleaning concentrate must be diluted before use according to the dosage instructions on the product. It must not be used undiluted.

Koboclean is a cleaning agent and not a disinfectant.


8.5 Getting ready for use

8.5.1 Standby position

Putting the device into standby position


You can only put the cordless handheld vacuum cleaner into standby position when it is centred.

- Push the cordless handheld vacuum cleaner forwards over the 2-in-1 wet and dry cleaning attachment.
- ⇒ *The cordless handheld vacuum cleaner clicks into the standby position.*




Taking the device out of standby position

1. Push the cordless handheld vacuum cleaner a little further forwards (1) until you hear a click.
- ⇒ *The cordless handheld vacuum cleaner is now no longer in the standby position.*
2. Put the cordless handheld vacuum cleaner in the power setting in the usual way (2).



8.5.2 Releasing the cloth holder

It is only possible to eject the cloth holder when the cordless handheld vacuum cleaner is tilted backwards on its rollers in the standby position.



1. Attach the 2-in-1 wet and dry cleaning attachment to the cordless handheld vacuum cleaner, see [Attaching and unlocking the accessory head](#) [▶ 26].
2. Put the cordless handheld vacuum cleaner in the standby position, see .
3. Tilt the cordless handheld vacuum cleaner backwards in the standby position (1).
⇒ *The 2-in-1 wet and dry cleaning attachment is now positioned on its rollers.*
4. Press the pedal (three green stripes) at the back of the 2-in-1 wet and dry cleaning attachment on the left-hand side with your foot (2).
⇒ *The cloth holder is released from the device.*

8.5.3 Attaching the cleaning cloth to the cloth holder




WARNING



Risk of choking!

Small parts may be accidentally swallowed and cause choking.

- Regularly check that the seam on the green nose of the cleaning cloth on the 2-in-1 wet and dry cleaning attachment is in good condition and replace it if the green nose is coming loose.



1. To attach the cleaning cloth to the cloth holder, push the green nose (1) of the cleaning cloth into the slot on the cloth holder between the arrows as far as it will go.
2. Then press the cloth holder directly onto the cloth (2).
⇒ *The back of the cloth is fastened to the cloth holder panel using Velcro and fits into place (3).*

3. Make absolutely sure that you do not attach the cloth to the cloth holder at an angle.

8.5.4 Removing, filling and inserting the tank


NOTICE



Material damage due to incorrect cleaning agents!

The improper use of cleaning agents when operating the 2-in-1 wet and dry cleaning attachment can cause damage.

- Only use original Kobold cleaning agents.
- Never use acid cleaning agents (e.g. vinegar-based cleaner) or highly alkaline cleaning agents (e.g. chlorine bleaching).



For wet cleaning, moisture is automatically applied to the cloth from the tank in the 2-in-1 wet and dry cleaning attachment.

1. Remove the tank from the 2-in-1 wet and dry cleaning attachment. To do this, gently pull up the green tank release mechanism at the back of the 2-in-1 wet and dry cleaning attachment (1) and pull the tank backwards to lift it out.

2. Unscrew the tank cap (2).

3. Fill the tank cap (3) with Koboclean as far as the line.


4. Pour this quantity into the tank (4). Please take note of the quantity indicated on the Koboclean cleaning concentrate.

5. Fill the tank with fresh tap water up to the maximum mark (5).


6. Put the cap back onto the tank and do it up.

7. Insert the tank into the 2-in-1 wet and dry cleaning attachment. This is done by first inserting the side with the cap into the 2-in-1 wet and dry cleaning attachment and then pressing the tank into its holder at the back.

⇒ *You will hear the tank click into place.*



8.5.5 Attaching the cloth holder



1. Place the cloth holder onto the floor with the cloth correctly attached.
2. Tilt the cordless handheld vacuum cleaner backwards in the standby position (1).
⇒ *The 2-in-1 wet and dry cleaning attachment is now positioned on its rollers.*
3. The cloth holder is symmetrical. To ensure that the cloth holder correctly engages with the 2-in-1 wet and dry cleaning attachment, roll the cordless handheld vacuum cleaner straight up to one of the long sides of the cloth holder.
4. Tip the cordless handheld vacuum cleaner onto the cloth holder (2).
⇒ *The cloth holder will click as it engages with the 2-in-1 wet and dry cleaning attachment (3). The device is now ready for use.*

8.5.6 Personalised cleaning setting

In the **MyKobold app** [▶ 32], you can configure the **suction power level** [▶ 31] of the cordless handheld vacuum cleaner for your 2-in-1 wet and dry cleaning attachment. The suction power of the cordless handheld vacuum cleaner will be set according to what you have entered and saved in the **MyKobold app** [▶ 32]. Your customised power level will then apply for all **moisture settings** [▶ 60].

1. **Connect the 2-in-1 wet and dry cleaning attachment to the cordless handheld vacuum cleaner** [▶ 26].
2. Follow the further instructions in the app.

8.6 Operation

8.6.1 Selecting the moisture setting


NOTICE



Damage to the floor from sharp-edged objects!


Sharp fragments underneath the cleaning cloth could cause damage to the floor.

- Before switching on the device, make sure that there are no small stones, granulates (e.g. cat litter) or other pointed or sharp-edged objects under the cleaning cloth.



- The moisture setting is selected using the +/- buttons (1).

8.6.2 Overview of moisture settings



1 Dry mode

The dots are lit, no waves are lit. The 2-in-1 wet and dry cleaning attachment is running without moisture in dry mode.

2 Single application of moisture

The waves are flashing from bottom to top. The initial application of moisture is activated by holding down the +/- button (for approx. 2 seconds). The cleaning cloth is saturated once per power cycle.

3 Moisture setting 1

One wave lit. The 2-in-1 wet and dry cleaning attachment is ready for use, the +/- button at the top has been pressed once, moisture is applied to the cleaning cloth on the lowest setting.

4 Moisture setting 2

Two waves lit. The 2-in-1 wet and dry cleaning attachment is ready for use, the +/- button at the top has been pressed twice, moisture is applied to the cleaning cloth on the medium setting.

5 Moisture setting 3

Three waves lit. The 2-in-1 wet and dry cleaning attachment is ready for use, the +/- button at the top has been pressed three times, moisture is applied to the cleaning cloth on the highest setting.


6 Boost mode

Three waves flashing. Hold down the boost button to temporarily switch the power level up to maximum.

7 Tank display/warnings

The *droplet* symbol is flashing. [Removing, filling and inserting the tank \[▶ 57\]](#).



The *warning triangle* and *droplet* symbols are flashing.  The 2-in-1 wet and dry cleaning attachment has vacuumed up moisture, see [Troubleshooting \[▶ 90\]](#).

8.6.3 Recommendations for moisture settings

Hard floor type	Dry	Setting 1	Setting 2	Setting 3
Sealed/varnished wooden floors (floorboards, parquet)	++	++	+	+
Oiled/waxed wooden floors	++	+	-	-
Unsealed/untreated wooden floors	++	-	-	-
Sealed cork floors	++	++	+	+
Oiled/waxed cork floors	+	-	-	-
Unsealed/untreated cork floors	+	-	-	-
Laminate	++	++	+	+
Elastic flooring (PVC, cushion vinyl, linoleum)	++	++	++	++
Stone floors (marble, granite, Jura limestone, artificial stone)	++	++	++	++
Porous/delicate natural stone (slate, clinker tiles)	++	++	++	++
Clay floors (terracotta, clinker, brick clay tiles)	++	++	++	++
Ceramic glazed tiles and fine stoneware	++	++	++	++
Untreated tiled floors	+	-	-	-
Rough concrete flooring (washed concrete)		excluded		
Textile flooring		excluded		

++ excellent suitability

+ very good suitability

- not suitable

Note The optimum moisture setting is also dependent on the speed with which you work. The quicker you work, the higher the moisture setting you can select.

If the floor becomes too wet while working with the 2-in-1 wet and dry cleaning attachment, you can switch to a lower setting. Alternatively, you can work for a few minutes without any moisture in dry mode.

If the cleaning cloth is too dry, increase the moisture setting using the +/- buttons on the handle.

Further guidance can be found under [Troubleshooting \[► 90\]](#).

NOTICE



Risk of damage to the floor!


The improper use of the 2-in-1 wet and dry cleaning attachment could cause damage to the floor.

- Never use the 2-in-1 wet and dry cleaning attachment without the cleaning cloth.
- Never work on the same spot for more than 10 seconds.
- Never leave the 2-in-1 wet and dry cleaning attachment standing on the floor with a wet cleaning cloth for more than 30 seconds as this could cause damage to delicate floors.
- Never dampen the cleaning cloth by hand. Moisture may only be applied to the cleaning cloth by the 2-in-1 wet and dry cleaning attachment. The cloth could otherwise become too wet.
- For delicate floors (such as floors which are not permanently sealed, e.g. oiled cork, oiled parquet, coated, oiled stoneware), try the device out in an inconspicuous area first to prevent damage to the floor.
- If floors that are extremely sensitive to moisture become too wet, wipe dry using a dry Parquet or Dry cleaning cloth and the vacuum cleaner.
- If the 2-in-1 wet and dry cleaning attachment gets jammed or caught on something, it should be switched off immediately in order to prevent damage.

1. Move the 2-in-1 wet and dry cleaning attachment back and forth in even lines.
2. Keep the 2-in-1 wet and dry cleaning attachment constantly moving.

Note Due to the special cleaning performance of the 2-in-1 wet and dry cleaning attachment, it is possible that, when using the device for the first time, floors will have to be cleaned several times in order to remove engrained dirt or cleaning residues.

8.6.5 Replacing the cleaning cloth



1. Release the cloth holder [▶ 56].
2. Take hold of the cloth holder.
3. With the other hand, take hold of the tab (1) on the cleaning cloth and fold it in half (2).
4. Place your thumb on the green nose of the cleaning cloth (3) and pull it out of the cloth holder (4).
5. Attach a clean cloth [▶ 56].

The service life of a cleaning cloth depends on how dirty the floor is and on the floor type.

8.6.6 Storage

1. Empty the tank [▶ 57] and remove the cleaning cloth [▶ 63].
2. Store the 2-in-1 wet and dry cleaning attachment with the tank and cloth holder installed.

8.6.7 Washing cleaning cloths



1. For best results, wash cleaning cloths before first use and after every subsequent use at 60°C in the washing machine without fabric softener.
2. The cleaning cloths can be tumble-dried on a low setting.

8.7 Maintenance

CAUTION



Risk of injury from moving parts!

Moving parts (such as the rotating brushes or oscillating cloth holder) could cause injury.

- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.
- Never reach into the moving parts.


8.7.1 Spare parts and consumables

We recommend you take advantage of our reorder options for original care products and original consumables in good time. For more details on the reorder options, see [Customer Service \[▶ 104\]](#) or the [MyKobold app \[▶ 32\]](#).

8.7.2 Removing the sealing lip frames


The sealing lips can be removed from the 2-in-1 wet and dry cleaning attachment to ensure that they can be thoroughly cleaned.

1. Place the 2-in-1 wet and dry cleaning attachment upside down on a soft surface.
2. Make sure that the pivot is facing towards you.
3. Pull the middle (1) of the sealing lip frame to release it from both holders (2).
4. Clean the sealing lip frames and, if necessary, rinse them under running water.



8.7.3 Mounting the sealing lip frames

The sealing lip frames must be completely dry before you put them back into the device. The two sealing lip frames are different in shape and have to be fitted on different sides. The end-to-end sealing lip of the frame must point inwards towards the cloth.



1. Hook the sealing lip frame under the double hook (1).
2. In order to engage the other side, push the sealing lip frame together slightly and insert it into position (2).
3. Check to ensure that the sealing lip frames can be easily moved up and down.
4. If the sealing lip frames are obstructed, clear the blockage by pressing the inner sealing lip edges down on the sealing lip frame.

8.7.4 Cleaning the tank

Rinse the tank regularly with clean water. If needed, you can also rinse out the tank with a mild soap solution.

8.8 Technical Data

Kobold SP7 2-in-1 wet and dry cleaning attachment


Safety symbols



Housing	high-quality, recyclable plastic
Motor	Maintenance-free brushless DC brush motor
Nominal output	55 W
Voltage	28.8 V
Weight	approx. 3.5 kg (without cloth and with an empty tank)
Dimensions	Height: approx. 10 cm (with horizontal joint) Width: approx. 32 cm Length: approx. 38 cm (with horizontal joint)
Tank volume	approx. 300 ml
Sound power level	76 dB(A) re 1 pW (with Kobold VK7 cordless handheld vacuum cleaner on a hard floor)

9 Kobold HD7 hard floor brush

9.1 Product overview



Overview of the Kobold HD7 hard floor brush

1 Pivot

2 Flipper

3 Sealing lip

4 Bristle plate (removable)

5 Slider for extending and retracting the sealing lip



9.2 Suitability for different types of floors

Hard floor type	Kobold HD7
Sealed/varnished wooden floors (floorboards, parquet)	++
Oiled/waxed wooden floors	+
Unsealed/untreated wooden floors	+
Sealed cork floors	++
Oiled/waxed cork floors	+
Unsealed/untreated cork floors	+
Laminate	++
Elastic flooring (PVC, cushion vinyl, linoleum)	++
Stone floors (marble, granite, Jura limestone, artificial stone)	+
Porous/delicate natural stone (slate, clinker tiles)	+
Clay floors (terracotta, clinker, brick clay tiles)	+
Ceramic glazed tiles and fine stoneware	++
Untreated tiled floors	+
Rough concrete flooring (washed concrete)	+
Carpets	-

- ++ excellent suitability
- + very good suitability
- not suitable

9.3 Operation

9.3.1 Extending the sealing lip




- Move the slider (1) on the underside of the hard floor brush to extend or retract the sealing lip.

With the sealing lip retracted (2), it is possible to vacuum larger particles of dirt. The extended position (3) is particularly suitable for cleaning floors with grooves.

9.3.2 Selecting the power level

- The power level is selected using the +/- buttons (1).



9.3.3 Overview of power levels



Display	Power level
1	Level 1 <i>min</i> for an extra long running time
2	Level 2 <i>med</i> for light dirt
3	Level 3 <i>med+</i> for everyday dirt on hard floors
4	Level 4 <i>max</i> for heavy dirt and floors with grooves
5	Boost Hold down the boost button to temporarily set the device to maximum power.

9.3.4 Vacuuming hard floors

1. Before using the hard floor brush, make sure that the device is [suitable for your floor](#) [▶ 67].
2. To vacuum efficiently, move the device back and forth in an even motion.

9.4 Maintenance

CAUTION



Risk of injury from moving parts!


You could injure yourself on moving parts.

- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.

9.4.1 Spare parts and consumables


We recommend you take advantage of our reorder options for original care products and original consumables in good time. For more details on the reorder options, see [Customer Service \[▶ 104\]](#) or the [MyKobold app \[▶ 32\]](#).

9.4.2 Removing blockages



1. Lay the hard floor brush on a soft surface with the underside facing upwards.
2. Open the inspection flap on the underside of the device.
3. Remove any objects that are blocking the suction channel. Use a suitable blunt object for this, if necessary (e.g. screwdriver, crochet hook).
4. Close the inspection flap again by inserting the tab on the inspection flap into the hard floor brush and pressing the other side downwards.

9.4.3 Changing the bristle plate



1. Lay the hard floor brush upside down on a soft surface.
2. Operate the release lever (3) to remove the bristle plate (1).
3. Pull the bristle plate upwards to remove it, and put it to one side (2).
4. Fit a new bristle plate by following the steps in reverse order. Make sure that it hooks into place under all the catches at the front.
5. Press the bristle plate down at the back of the release lever until it clicks into place.
6. Check again that the bristle plate is fully hooked in and locked into place at the front.


9.5 Technical Data

Kobold HD7 hard floor brush

Weight	approx. 950 g
Maximum nozzle width	approx. 270 mm
Nozzle height (with horizontal joint)	approx. 75 mm
Sound power level	78 dB(A) re 1pW (with Kobold VK7 cordless handheld vacuum cleaner on a hard floor)

10 Kobold PB7 electric upholstery brush with Kobold MP7/MR7 mattress cleaning set

10.1 Product overview



Overview of the Kobold PB7 electric upholstery brush

1 Hose	6 Attachment socket
2 Slider switch	7 Kobold MP7 mattress freshening accessory
3 Suction shoe opening for crevices	8 Lavenia mattress cleaning powder
4 Recessed grip	9 Kobold MR7 mattress deep cleaning accessory
5 Recessed grip	

10.2 Operation

When using the cordless handheld vacuum cleaner in combination with the electric upholstery brush, you can either lay the cordless handheld vacuum cleaner flat, hold the cordless handheld vacuum cleaner in your hand with the **rotating handle folded in** [▶ 25] or **use the shoulder strap** [▶ 89].


10.2.1 Overview of power levels and Lavenia mode



Display	Power level
1	Lavenia mode The motor on the cordless handheld vacuum cleaner switches off, leaving only the motor on the automatic electric floor brush running. This means that only the brushes are rotating.
2	<i>min</i> setting If the electric upholstery brush is attached, the cordless handheld vacuum cleaner will start on this power level every time it is switched on.
3	<i>med</i> setting
4	<i>max</i> setting Maximum power for dirt in crevices, grooves and similar areas that is difficult to vacuum.
5	Boost Hold down the boost button to temporarily set the device to maximum power.


10.2.2 Cleaning upholstery

1. Take the cordless vacuum cleaner in your hand or lay it down on the upholstery next to the area that is going to be cleaned.
2. Do not pull the cordless handheld vacuum cleaner across the floor.
3. Change the power settings using the +/- buttons.
4. Select the most suitable power setting depending on how dirty the floor is.




10.2.3 Vacuuming surfaces

1. Move the green slider (1) into the position *vacuum surfaces* (2).
2. During the cleaning process, place the suction openings of the electric upholstery brush completely on the upholstery.
3. Gently move the device over the upholstery without applying pressure.



10.2.4 Vacuuming crevices


1. Move the green slider (1) into the *vacuum crevices* (3) position.
2. It is best to use maximum power for dirt in crevices, grooves and similar areas that is difficult to vacuum.




10.2.5 Cleaning mattresses

We recommend Lavenia mattress cleaning powder for cleaning mattresses. Lavenia has been certified as being suitable for allergy sufferers by TÜV NORD.


Lavenia can be used with all mattresses with textile and solid surfaces. Lavenia is not suitable for cleaning upholstered furniture. One bag of Lavenia is enough to thoroughly clean an area of mattress measuring 1m x 2m.




1. Pull the suction shoe (1) down at the recessed grip and away from the electric upholstery brush.



2. Connect the mattress deep cleaning accessory (2) to the electric upholstery brush (4) by first hooking the latches (3) into the electric upholstery brush and then fitting the attachment to the electric upholstery brush with a swivel motion.




3. Switch on the cordless handheld vacuum cleaner. The slide switch on the electric upholstery brush must be switched to the setting for vacuuming surfaces (5).
4. Vacuum the mattress with the mattress deep cleaning accessory.
5. Switch off the cordless handheld vacuum cleaner.
6. Spread the contents of a bag of Lavenia mattress cleaning powder (120 g) evenly over the mattress.
7. Swap the attachments. Pull the mattress deep cleaning accessory down and away from the electric upholstery brush by the recessed grip.



8. Connect the mattress freshening accessory (6) to the electric upholstery brush by first hooking the latches into the electric upholstery brush and then fitting the attachment to the electric upholstery brush with a swivel motion.




9. Switch the cordless handheld vacuum cleaner to Lavenia mode by pressing the lower +/- button once.
 ⇒ *The nubbed disc will start to rotate. The motor on the cordless handheld vacuum cleaner switches off, leaving only the motor on the automatic electric floor brush running.*



10. Using the mattress freshening accessory (8), work in Lavenia (7) for 2-3 minutes on an area of about 1 x 2 metres. When working Lavenia in, do not apply any pressure on the mattress freshening accessory.


If you apply too much pressure on the mattress freshening accessory, the automatic electric floor brush will automatically switch off to protect the mattress from getting damaged. Should you have pressed too firmly, switch the cordless handheld vacuum cleaner off and back on again to continue working with the automatic electric floor brush.

11. Allow the powder (7) to dry thoroughly for at least 30 minutes. Make sure that the room is well ventilated.



12. Then exchange the mattress freshening accessory (8) for the mattress deep cleaning accessory (11). To do so, slide the green release button (10) outwards to release the lock and then remove the mattress freshening accessory.

13. Connect the mattress deep cleaning accessory (11) to the electric upholstery brush (9) by first hooking the latches into the electric upholstery brush and then fitting the attachment to the electric upholstery brush with a swivel motion.



14. Switch on the cordless handheld vacuum cleaner. The slide switch on the electric upholstery brush must be switched to the setting for vacuuming surfaces (12).
15. Vacuum the dry Lavenia powder using the electric upholstery brush with the mattress deep cleaning accessory on power setting 'med'.

10.3 Maintenance

CAUTION



Risk of injury from moving parts!


You could injure yourself on moving parts.

- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.
- Never reach into the moving parts.
- Do not operate the electric upholstery brush without an attachment.
- Do not remove mattress-cleaning attachments while the electric upholstery brush is in operation.

10.3.1 Spare parts and consumables


We recommend you take advantage of our reorder options for original care products and original consumables in good time. For more details on the reorder options, see [Customer Service \[▶ 104\]](#) or the [MyKobold app \[▶ 32\]](#).

10.3.2 Maintenance of the electric upholstery brush



1. Disconnect the electric upholstery brush from the cordless handheld vacuum cleaner.
2. Detach the suction shoe (1) by pulling downwards.
3. Brush or wipe the device dry.
4. Check the suction shoe every once in a while to ensure that no threads or hairs have coiled around the roller brushes.
5. Cut any threads or hairs with a small pair of scissors.
6. When connecting the suction shoe (2), first insert the latches on the shoe (3) into the designated openings on the electric upholstery brush (4) by hooking them in and then fitting the attachment to the electric upholstery brush with a swivel motion.
7. Holding the recessed grip, press the suction shoe firmly against the device. Make sure that you can hear the suction shoe engage.

10.3.3 Cleaning the mattress freshening accessory



After the cleaning process, Lavenia residue may be stuck to the nubbed disc which impairs functionality during subsequent use.

1. Check the nubbed disc for residual dirt after every mattress cleaning.

2. Vacuum away any Lavenia residue.


The nubbed disc can also be removed for cleaning under running water. Proceed as follows:

1. Attach the mattress freshening accessory (2) to the electric upholstery brush (1).

2. Turn the nubbed disc to release it (bayonet closure) (3). Note the symbol (lock) on the nubbed disc.

3. After cleaning and drying the nubbed disc, reinstall it by turning it in the opposite direction (4). *tbc*

10.3.4 Cleaning the mattress deep cleaning accessory



Lavenia may stick to the mattress deep cleaning accessory.

1. After each use, check the mattress deep cleaning accessory for Lavenia residue.
2. Pull the mattress deep cleaning accessory (1) down and away from the electric upholstery brush by the recessed grip.
3. Vacuum away any Lavenia residue. Never wet-clean the mattress deep cleaning accessory or electric upholstery brush.
4. Connect the mattress deep cleaning accessory (2) to the electric upholstery brush (4) by first hooking the latches (3) into the electric upholstery brush and then fitting the attachment to the electric upholstery brush with a swivel motion.

10.4 Technical Data

Kobold PB7 electric upholstery brush with Kobold MP7 mattress freshening accessory and Kobold MR7 mattress deep cleaning accessory


Safety symbols



Housing	High-quality recyclable plastic, with suction shoe made of shatter-proof polyamide
Motor	Maintenance-free DC motor with direct transmission
Brush mechanism	2 counter-rotating roller brushes with approx. 4000 rpm, maintenance-free bearings
Nominal output	35 watts
Voltage	28.8 V
Weight	Kobold PB7 electric upholstery brush: approx. 1200 g Kobold MP7 mattress freshening accessory: approx. 440 g Kobold MR7 mattress deep cleaning accessory: approx. 150 g
Dimensions	Kobold PB7 electric upholstery brush (with tube): Height approx. 10 cm; width approx. 8 cm; length approx. 154 cm Kobold MP7 mattress freshening accessory: Height approx. 6 cm; width approx. 18 cm; length approx. 20 cm Kobold MR7 mattress deep cleaning accessory: Height approx. 7 cm; width approx. 8 cm; length approx. 18 cm
Sound power level	82 dB(A) re 1 pW (with Kobold VK7 cordless handheld vacuum cleaner based on EN 60704-2-1 on upholstery fabric) 85 dB(A) re 1 pW (with Kobold VK7 cordless handheld vacuum cleaner with MP7 mattress freshening accessory on a mattress) 82 dB(A) re 1 pW (with Kobold VK7 cordless handheld vacuum cleaner with MR7 mattress deep cleaning accessory on a mattress)

11 Kobold PC7 dual battery charger


11.1 Product overview



Overview of the Kobold PC7 dual battery charger

1 Kobold PC7 dual battery charger with battery installed	4 Kobold WM7 wall mount for the cordless handheld vacuum cleaner
2 Charging connector	5 Kobold WMP7 mounting plate for the dual battery charger
3 Mains cable	

11.2 Connecting the mains cable



- Plug the mains cable (1) into the socket (2) on the underside of the dual battery charger.

11.3 Mounting the device on a wall

Using the dual battery charger, you can hang up and store the cordless vacuum cleaner and charge it at the same time.

WARNING



Risk of electric shock!


Drilling mounting holes in the wall could result in an electric shock.

- When drilling (especially near a power socket or light switch), take particular care to ensure that you do not drill through an electric cable.

11.3.1 Selecting a location for the wall mount

The location for hanging your cordless handheld vacuum cleaner should ideally meet the following criteria:

- Near to a power socket **But never directly in the line above or below a power socket**, as there are very likely to be electrical cables there. Always consider the layout of your home and check where electrical cables are located.
- At a height of at least 65 cm above the floor but **not higher than 100 cm**.
- In an area that is at least 30 cm wide to allow sufficient space for the cordless handheld vacuum cleaner and accessory head.






For step-by-step instructions, please refer to the installation guide supplied with the Kobold PC7 dual battery charger.

11.4 Charging with the dual battery charger

For instructions on charging the cordless handheld vacuum cleaner with the Kobold SC7 single charger, see [Charging with the single charger](#) [▶ 28].

11.4.1 Charging for the first time with the dual battery charger




A new battery is not fully charged on delivery and is set to transport mode.


- To start charging it for the first time or after deep discharge, press the activation button (2) on the left-hand side of the dual battery charger housing (1).
- ⇒ *The display lights up, charging is active, see [Charging display](#) [▶ 29].*

11.4.2 Charging the cordless handheld vacuum cleaner with the dual battery charger

Charging the cordless handheld vacuum cleaner while mounted on the wall



1. Note the prescribed mains voltage of 220-240 V AC.
 2. Connect the dual battery charger (1) to the power supply.
 3. Hang the cordless handheld vacuum cleaner with its charging connection (2) on the wall mount (3).
- ⇒ *The display (4) lights up, charging is active [▶ 29].*
- ⇒ *If the display (4) does not light up, press the activation button on the side of the dual battery charger [▶ 84].*




Charging the cordless handheld vacuum cleaner while upright

1. Put the cordless handheld vacuum cleaner into the **standby position** [▶ 26].
2. Place the dual battery charger on a clean, solid and even surface so that it cannot slip.
3. Note the prescribed mains voltage of 220-240 V AC.
4. Connect the mains cable to the power supply.
5. Insert the charging connector (2) into the socket on the cordless handheld vacuum cleaner (1) and slide it upwards.
 - ⇒ *The display lights up, charging is active* [▶ 29].
 - ⇒ *If the display (4) does not light up, press the activation button on the side of the dual battery charger* [▶ 84].


11.4.3 Charging a separate battery with the dual battery charger

If the cordless handheld vacuum cleaner and separate battery are connected to the dual battery charger, the cordless vacuum cleaner, which is connected to the charging connector, will be charged first. The battery inside the dual battery charger will be automatically charged afterwards.



Charging a separate battery (wall-mounted)

1. Insert the lower edge of the battery (5) into the dual battery charger (6).
2. Then lower the top end of the battery into the charging cradle.
3. Press the lever on the battery (7) until it clicks into place.
 - ⇒ *The display (8) lights up, charging is active* [▶ 29].
 - ⇒ *If the display (8) does not light up, press the activation button on the side of the dual battery charger* [▶ 84].



Charging a separate battery

1. Place the dual battery charger (1) on a clean, solid and even surface so that it cannot slip.
2. Note the prescribed mains voltage of 220-240 V AC.
3. Connect the mains cable to the power supply.
4. Insert the lower edge of the battery (2) from above into the dual battery charger.
5. Lower the top end of the battery into the charging cradle.
6. Press the lever on the battery until it clicks into place.
 - ⇒ *The display lights up, charging is active* [▶ 29].
 - ⇒ *If the display does not light up, press the activation button on the side of the dual battery charger* [▶ 84].

11.5 Technical Data

Kobold PC7 dual battery charger

Name or trade mark of the manufacturer, company registration number and address	Vorwerk Elektrowerke GmbH & Co. KG HRB 7852 Mühlenweg 17-37 42270 Wuppertal, Germany
---	---

Type designation	PC7
------------------	-----

Input voltage	220-240V AC
---------------	-------------

Input AC frequency	50/60 Hz (automatic adjustment)
--------------------	---------------------------------

Output voltage	37V DC
----------------	--------



Output current	1.3 A
----------------	-------

Output power	48.1 W
--------------	--------

Average active efficiency	> 87.77 %
---------------------------	-----------

Efficiency at low load (10 %)	> 75 %
-------------------------------	--------

Power consumption at zero load	0 W
--------------------------------	-----

Safety symbols	 
----------------	---



12 Kobold accessories

12.1 Nozzle set

NOTICE




Risk of damage from improper use!

Using the nozzle set (Kobold accessories) incorrectly could damage surfaces.

- Do not use nozzles from the nozzle set on smooth or polished surfaces.

The nozzle set contains a range of accessories and attachments to help you with a wide range of cleaning tasks around the home.



- Connect the extendable suction hose to the cordless handheld vacuum cleaner. The following nozzles can be attached to it.
- When cleaning with the nozzles, make sure that you hold the cordless handheld vacuum cleaner securely or set it down safely.




The surface nozzle (1) is multi-functional and can be used on a wide variety of surfaces.

It also comes with a bristle guard. The bristle guard can be used when the nozzle is in storage.


Make sure that it is removed before vacuuming.



The car nozzle (2) is ideal for cleaning car interiors.



The telescopic tube is ideal for reaching high areas. For example, in combination with the surface nozzle (3) or textile nozzle.




The variable nozzle is extremely versatile. It has two attachments that can be used for a number of different tasks:

- (5) Extendable, flexible tip for narrow spaces
- (6) Crevice brush: for very small gaps, skirting boards
- (7) Drilling attachment: for vacuuming while drilling




The textile nozzle (8) has been specially developed for vacuuming upholstered furniture and fabrics.

12.2 Unlocking accessories



- To remove accessories, slide the release button (1) on the accessory backwards (2) and then disconnect the accessory.

12.3 Kobold SG7 shoulder strap



You can attach the Kobold SG7 shoulder strap to your cordless handheld vacuum cleaner. With the cordless handheld vacuum cleaner secured by the shoulder strap, you no longer need to hold it and will have both hands free while vacuuming.

1. Make sure that the **rotating handle is open** [▶ 25].
2. Slide the loop of the shoulder strap (1) over the front part of the cordless handheld vacuum cleaner (2).
3. Fold the rotating handle into the handle lock (3).
4. Hang the strap hook (4) on the fastener above the air outlet on the cordless handheld vacuum cleaner (5) (for the orientation of the hook, see illustration above).
5. Pull the hook upwards until you hear it click into position (6).

13 Troubleshooting

CAUTION












Risk of injury from moving parts!







You could injure yourself on moving parts.




- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.
- Never reach into the moving parts.

13.1 Troubleshooting by error code

Error code	Cause	Troubleshooting
00	The cordless handheld vacuum cleaner will not start because the battery is not charged.	<ul style="list-style-type: none">- Charge the battery [▶ 27].- If the error persists, please contact Service [▶ 104].
Er 10 + symbol	General fault on the cordless handheld vacuum cleaner.	<ul style="list-style-type: none">- Remove and reinstall the battery [▶ 39] and switch the cordless vacuum cleaner on.- If the error persists, please contact Service [▶ 104].
Er 11 + symbol	The cordless handheld vacuum cleaner has overheated.	<ul style="list-style-type: none">- Allow the cordless handheld vacuum cleaner to cool down at room temperature.- Change the premium filter bag if necessary [▶ 37].- Clear the flow paths. Remove the accessory head [▶ 26] and remove any dirt from the suction tube on the cordless handheld vacuum cleaner.- Clear any blockages from the accessory head.
Er 14 + symbol	The fan inlet is blocked by a foreign object.	<ul style="list-style-type: none">- Remove the foreign object from the fan outlet in the filter compartment on the cordless handheld vacuum cleaner.- If the error persists, please contact Service [▶ 104].
Er 19 + symbol	General fault on the cordless handheld vacuum cleaner.	<ul style="list-style-type: none">- Remove and reinstall the battery [▶ 39] and switch the cordless handheld vacuum cleaner on.- If the error persists, please contact Service [▶ 104].
Er 23 + symbol	There is a fault with the electrical contacts on the battery.	<ul style="list-style-type: none">- Remove the battery [▶ 39].- Check the contacts for contamination.- Reinstall the battery and charge it [▶ 27].

Error code	Cause	Troubleshooting
		<ul style="list-style-type: none"> - If the error persists, please contact Service [▶ 104].
Er 25 + symbol 	Internal fault with the battery.	<ul style="list-style-type: none"> - If this error code appears on the display, contact Service [▶ 104].
Er 26 + symbol 	The battery is undercooled.	<ul style="list-style-type: none"> - Allow the battery to warm up at room temperature.
Er 27 + symbol 	Battery authentication failed.	<ul style="list-style-type: none"> - Remove the battery [▶ 39]. - Only use an original Vorwerk battery.
Er 28 + symbol 	Battery charging fails.	<ul style="list-style-type: none"> - Disconnect the charger from the power supply. - Disconnect the charger from the cordless handheld vacuum cleaner or from the charging adapter for the charger. - Remove the battery [▶ 39]. - Check the battery contacts for contamination. - Check the contacts on the charging connector for contamination, and also the charging connection on the cordless handheld vacuum cleaner/charging adapter for the charger. - Restore all charging connections. - Charge the battery [▶ 27].
Er 29 + symbol 	The cordless handheld vacuum cleaner will not switch off.	<ul style="list-style-type: none"> - Remove the battery [▶ 39]. - Reinstall the battery. - If the error persists, please contact Service [▶ 104].
Er 30 + symbol 	General fault on the 2-in-1 wet and dry cleaning attachment.	<ul style="list-style-type: none"> - Remove and reinstall the battery [▶ 39] and switch the cordless handheld vacuum cleaner on. - If the error persists, please contact Service [▶ 104].
Er 32 + symbol 	The motor on the 2-in-1 wet and dry cleaning attachment is overloaded.	<ul style="list-style-type: none"> - Test the 2-in-1 wet and dry cleaning attachment on different floors and/or try a different floor/cloth combination. - If the error persists, please contact Service [▶ 104].
Er 35 + symbols  	Moisture has been absorbed by the 2-in-1 wet and dry cleaning attachment.	<p>The device is not a wet vacuum cleaner and switches to error mode if liquid is vacuumed.</p> <ul style="list-style-type: none"> - Switch the cordless handheld vacuum cleaner off. - Open the inspection flap (1) on the 2-in-1 wet and dry cleaning attachment. - Dry the area with a kitchen towel.

Error code	Cause	Troubleshooting
		<ul style="list-style-type: none"> - Once the device is completely dry, close the inspection flap and switch the cordless handheld vacuum cleaner on again. - Do not vacuum wet areas. - Repeat the process if the fault continues to occur.
Er 36 + symbol 	There is a fault with the electronics on the 2-in-1 wet and dry cleaning attachment.	<ul style="list-style-type: none"> - Switch the cordless handheld vacuum cleaner off and back on again.
Er 40 + symbol 	General fault on the automatic electric floor brush.	<ul style="list-style-type: none"> - Remove and reinstall the battery [▶ 39] and switch the cordless handheld vacuum cleaner on. - If the error persists, please contact Service [▶ 104].
Er 41 + symbol 	The automatic electric floor brush has overheated.	<ul style="list-style-type: none"> - Allow the device to cool down at room temperature. - Change the premium filter bag if necessary [▶ 37]. <p>The suction duct of the automatic electric floor brush may be blocked.</p> <ul style="list-style-type: none"> - Open the inspection flap (1) on the underside of the automatic electric floor brush. - Remove the blockage. - If necessary, use an appropriate object to do this (e.g. crochet needle). - Put the inspection flap (1) back on.
		
Er 42 + symbol 	The motor on the automatic electric floor brush is overloaded.	<p>A vacuumed object may be blocking the roller brushes on the automatic electric floor brush.</p> <ul style="list-style-type: none"> - Switch the cordless handheld vacuum cleaner off. - Disconnect the automatic electric floor brush from the cordless handheld vacuum cleaner. - Remove the blockage from the roller brush. <p>Threads or hairs may be blocking the roller brushes on the automatic electric floor brush.</p> <ul style="list-style-type: none"> - Cut and remove the threads [▶ 50]. <p>A very soft, thick carpet or deep-pile carpet may put greater stress on the roller brushes on the automatic electric floor brush.</p>

Error code	Cause	Troubleshooting
		<ul style="list-style-type: none"> – Briefly lift up the automatic electric floor brush from the carpet and place it down on a hard floor. – Deactivate the roller brushes [▶ 46] and continue cleaning the carpet. – Use a lower suction power level [▶ 46] if necessary.
Er 43 + symbol 	There is a fault with the electrical contacts on the automatic electric floor brush.	<ul style="list-style-type: none"> – Remove the automatic electric floor brush. – Check whether the contacts on the connection between the automatic electric floor brush and cordless handheld vacuum cleaner are contaminated, and clean them if necessary.
Er 46 + symbol 	There is a fault with the electronics on the automatic electric floor brush.	<ul style="list-style-type: none"> – Switch the cordless handheld vacuum cleaner off and back on again.
Er 63 + symbol 	General fault on the accessory head.	<ul style="list-style-type: none"> – Remove the accessory head. [▶ 26] – Check whether the contacts on the connection between the accessory head and cordless handheld vacuum cleaner are contaminated, and clean them if necessary.

13.2 Troubleshooting by fault description

Kobold VK7 cordless handheld vacuum cleaner

CAUTION



Risk of injury from moving parts!

You could injure yourself on moving parts.

- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.
- Never reach into the moving parts.

Fault	Possible cause and rectification
Bluetooth® does not switch off.	<ul style="list-style-type: none"> – Press one of the +/- buttons and the boost button at the same time for at least 6 seconds (1).



The battery is defective (possible indicators: The display is blank when charging and the cordless handheld vacuum cleaner does not work after the battery has been charged.

The battery may have overheated or may be undercooled.

- Remove the battery.
- Allow the battery to warm up or cool down for a day at room temperature.
- Contact [customer service](#) [▶ 104].
- Dispose of the battery safely according to regulations.

The battery does not appear to be working.


If you have a Kobold SC7 single charger:

- Connect the charger to the cordless handheld vacuum cleaner or the separate charging adapter.
- Make sure that the battery is correctly inserted in the cordless handheld vacuum cleaner or the charging adapter.
- Press the reset button (2) on the base of the charger with a suitable implement (1).
- Fully charge the battery.

If you have a Kobold PC7 dual battery charger:

- Follow the steps described in [Charging for the first time with the dual battery charger](#) [▶ 84].

If the battery level drops sharply to 0%, fully charge the battery.




When vacuuming, a change in suction power can be heard.

The intelligent motor protection system automatically sets the optimum power level for the cordless handheld vacuum cleaner.

The suction power on the cordless handheld vacuum cleaner does not increase even though a higher power setting has been selected.

- Move the nozzle back and forth on the upholstery.
- Check the air ducts and the premium filter bag for blockages.
- Do not store the cordless handheld vacuum cleaner in hot places (e.g. in the car in summer, in direct sunlight).
- Allow the cordless handheld vacuum cleaner to cool down at room temperature.

Fault	Possible cause and rectification
<p>Remote unlocking does not work. The accessory head does not detach at the rotating handle.</p> 	<p>Remote unlocking may be defective. Use the emergency unlocking function to disconnect the accessory head.</p> <ul style="list-style-type: none"> - Remove the filter cover ▶ 36]. - Using a narrow object (such as a screwdriver or ruler), press the white emergency unlocking button (1). - Remove the accessory head while the emergency unlocking button is activated.

Kobold EB7 automatic electric floor brush


CAUTION




Risk of injury from moving parts!

Moving parts (such as the rotating brushes) could cause injury.

- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.
- Never reach into the moving parts.

Fault	Possible cause and rectification
<p>The <i>filter change</i> symbol lights up or flashes even though the premium filter bag is not completely full.</p> 	<p>The suction duct of the automatic electric floor brush may be blocked.</p> <ul style="list-style-type: none"> - Open the inspection flap (1) on the underside of the automatic electric floor brush. - Remove the blockage. - If necessary, use an appropriate object to do this (e.g. crochet needle). - Put the inspection flap (1) back on.

Fault**Possible cause and rectification**



When vacuuming very thick carpets, the *filter change* symbol can light up even though the filter bag does not need to be changed.

- Move the nozzles gently back and forth as you vacuum.

The frequency with which the *filter change* symbol recommends the replacement of the premium filter bag depends on what is vacuumed. A large quantity of fine dust may have been vacuumed.

- **Change the premium filter bag** [▶ 37].
-

The Kobold automatic electric floor brush is too loud.

The roller brushes may not be correctly inserted.

- Check whether the roller brushes are correctly inserted.
- If one of the roller brushes is defective, always replace both brushes.

It may be that original Kobold accessories were not used, which could result in damage to the bearing and motor.

- Use original Kobold roller brushes only.

An object may have become stuck in the area of the roller brushes.

- Remove the object.

There may be loud noises when working on hard floors.

- The 'power level 4 – carpet max' brush mode is not suitable for hard floors and can make loud noises if used on hard floors. Switch to a different brush mode.

Hairs may be coiled around the roller brushes.

- **Clean the roller brushes** [▶ 49].

You may have run over a threshold (the transition between two different floors) too slowly.

- Cross thresholds as quickly as possible (within one second).

You may be vacuuming a very short-pile carpet and the auto mode switched between carpet and hard-floor mode.

- Use the **personalised cleaning setting** [▶ 47].
-

Threads and hairs have coiled around the roller brush.


Threads and hairs may be blocking the roller brushes on the automatic electric floor brush.

- **Cut and remove the threads and hairs** [▶ 50].
 - Remove threads, hairs and fibres from the metal shaft if necessary.
-

The automatic electric floor brush is not vacuuming properly.

The suction duct of the automatic electric floor brush may be blocked.

Fault**Possible cause and rectification**



- Open the inspection flap (1) on the underside of the automatic electric floor brush.
- Remove the blockage.
- If necessary, use an appropriate object to do this (e.g. crochet needle).
- Put the inspection flap (1) back on.

The premium filter bag may be full.

- [Change the premium filter bag \[▶ 37\]](#).

The automatic electric floor brush is hard to push.

You might have set the suction power level too high.

- Select a lower suction power level on the handle of the cordless handheld vacuum cleaner.

After replacing the roller brushes, the device does not work anymore.

The roller brushes may not be correctly inserted.

- [Position the roller brushes precisely on the drive shafts \[▶ 50\]](#).

The automatic electric floor brush may not be correctly connected to the cordless handheld vacuum cleaner.

- Check if the connection between the automatic electric floor brush and the cordless handheld vacuum cleaner is correctly engaged.

The auto mode does not work as usual.

The roller brushes may be dirty.

- [Clean the roller brushes \[▶ 49\]](#).

Original Kobold accessories may not have been used.

- Use original Kobold roller brushes only.

The roller brushes may not have been correctly inserted.

- [Position the roller brushes precisely on the drive shafts \[▶ 50\]](#).

The front or rear sealing lip is defective.

The front sealing lip is defective.

- Send the automatic electric floor brush to [customer service \[▶ 104\]](#).

The rear sealing lip is defective.

- Order a new rear sealing lip.
 - [Change the rear sealing lip \[▶ 51\]](#).
-

CAUTION




Risk of injury from moving parts!

Moving parts (such as the rotating brushes or oscillating cloth holder) could cause injury.

- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.
- Never reach into the moving parts.

Fault

The *filter change* symbol lights up or flashes even though the filter bag is not full.



Possible cause and rectification

The suction channel of the 2-in-1 wet and dry cleaning attachment may be blocked.

- Switch the cordless handheld vacuum cleaner off.
- Open the inspection flap on the left-hand side of the device. This can be done by inserting a coin into the groove (1). You can now clearly see inside the suction channel (2).
- Remove any objects that are blocking the suction channel. Use a suitable blunt object for this, if necessary (e.g. screwdriver, crochet hook).
- Press the inspection flap down to close it again. The latch on the inspection flap will click into place and it is now firmly closed.
- Also check whether the suction openings between the sealing lip frames are clear. If necessary, shake out any objects inside.

The frequency with which the *filter change* symbol recommends the replacement of the premium filter bag depends on what is vacuumed. A large quantity of fine dust may have been vacuumed.

- **Change the premium filter bag** [▶ 37].

The joint connector of the 2-in-1 wet and dry cleaning attachment is blocked.


- Remove the blockage with a suitable blunt tool (e.g. screwdriver, crochet hook).

The 2-in-1 wet and dry cleaning attachment is making unusual noises.

The inspection flap may not be closed properly or the cloth holder frame may not be correctly fitted.

Fault	Possible cause and rectification
	<ul style="list-style-type: none"> - Check whether the inspection flap is closed properly and, if not, close it. - Check the cloth holder frame is correctly inserted and fastened into place. <p>It is possible that the water tank is not correctly installed.</p> <ul style="list-style-type: none"> - Switch the cordless handheld vacuum cleaner off. - Insert the tank [▶ 57]. - Switch the cordless handheld vacuum cleaner back on again.
<p>The 2-in-1 wet and dry cleaning attachment is swivelling excessively.</p>	<p>The cleaning cloth is not fixed properly.</p> <ul style="list-style-type: none"> - Check whether the cleaning cloth is straight and firmly fixed on the cloth holder frame. - Check whether the green nose of the cleaning cloth has been correctly and fully pushed in. <p>The cloth holder frame is not inserted correctly.</p> <ul style="list-style-type: none"> - Check whether the 2-in-1 wet and dry cleaning attachment has correctly engaged with the cloth holder frame. - It is possible that original Kobold cleaning cloths were not used. - Only use original Kobold cleaning cloths. - Use the Kobold MF600 Universal cleaning cloth on rough floors.
<p>The 2-in-1 wet and dry cleaning attachment leaves streaks/marks on the floor.</p>	<p>It is possible that the sealing lip frames are dirty and jammed.</p> <ul style="list-style-type: none"> - Remove the front sealing lip frame [▶ 64]. <p>It is possible that the cleaning cloth is soiled excessively.</p> <ul style="list-style-type: none"> - Change the cleaning cloth [▶ 63].
<p>The 2-in-1 wet and dry cleaning attachment is not vacuuming effectively.</p>	<p>It is possible that the sealing lip frames are dirty and jammed.</p> <ul style="list-style-type: none"> - Remove the sealing lip frames [▶ 64] and clean them. - Also check whether the suction openings between the sealing lips are clear from underneath. If necessary, shake out any objects inside. - Check whether the sealing lip frames are able to move. <p>The cleaning cloth may be attached to the cloth holder frame at an angle and be obstructing the sealing lip frames.</p> <ul style="list-style-type: none"> - Check whether the cleaning cloth is evenly fixed on the cloth holder frame. <p>The suction channel may be blocked.</p> <ul style="list-style-type: none"> - Open the inspection flap on the left-hand side of the 2-in-1 wet and dry cleaning attachment to clear any blockages. This can be done by inserting a coin into the groove and rotating it slightly (1).

Fault**Possible cause and rectification**



The latch on the inspection flap opens. You can now open the inspection flap further to get a clear view of the suction channel (2).

- Remove any objects that are blocking the suction channel. Use a suitable blunt object for this, if necessary (e.g. screwdriver, crochet hook).
- Press the inspection flap down to close it again. The latch on the inspection flap will click into place and it is now firmly closed.

The cleaning performance of the 2-in-1 wet and dry cleaning attachment is getting worse.



It is possible that the cleaning cloth is soiled excessively.

- **Change the cleaning cloth** [▶ 63].

The cleaning cloth may be too dry.

- Check the display on the cordless handheld vacuum cleaner. If the *droplet* symbol is flashing, you need to **fill the tank** [▶ 57].
- Activate a single application of moisture if you have not done so already, or switch to a **suitable moisture setting** [▶ 59].

Streaks are forming.

It is possible that the cleaning cloth was not washed prior to first use.

- **Wash the cleaning cloth prior to first use** [▶ 63].

It is possible that too much cleaning agent was used.

- Repeat the cleaning process with a new cleaning cloth and clean water.

It is possible that there are residual quantities of old care products and cleaning agents on the floor.

- Repeat the cleaning process until it improves; a thorough clean might be required.

It is possible that the cleaning cloth is soiled excessively.

- **Change the cleaning cloth** [▶ 63].

The film of moisture does not dry evenly.

- Go over the floor again using the 2-in-1 wet and dry cleaning attachment in dry mode with a dry cleaning cloth to remove residual liquid.
-

Fault	Possible cause and rectification
<p>The 2-in-1 wet and dry cleaning attachment cleans edges insufficiently.</p>	<p>It is possible that the cleaning cloth has not been fixed properly.</p> <ul style="list-style-type: none"> - Check whether the cleaning cloth is straight and firmly fixed on the cloth holder frame. <p>It is possible that the cleaning cloth was not washed prior to first use.</p> <ul style="list-style-type: none"> - Wash the cleaning cloth prior to first use [▶ 63]. <p>The cleaning cloth may be too dry.</p> <ul style="list-style-type: none"> - Check the display on the cordless handheld vacuum cleaner. If it shows the <i>droplet</i> symbol, you need to fill the tank [▶ 57]. - Activate a single application of moisture if you have not done so already, or switch to a suitable moisture setting [▶ 59].
<p>There is still a thin layer of dirt on the floor.</p>	<p>It is possible that the cleaning cloth is soiled excessively.</p> <ul style="list-style-type: none"> - Change the cleaning cloth [▶ 63].
<p>Stain removal is insufficient.</p>	<p>It is possible that the cleaning cloth is soiled excessively.</p> <ul style="list-style-type: none"> - Change the cleaning cloth [▶ 63]. <p>The cleaning cloth may be too dry.</p> <ul style="list-style-type: none"> - Check the display on the cordless handheld vacuum cleaner. If it shows the <i>droplet</i> symbol, you need to fill the tank [▶ 57]. - Activate a single application of moisture if you have not done so already, or switch to a suitable moisture setting [▶ 59].
<p>After cleaning, the floor looks tarnished.</p>	<p>There may be residual quantities of old care products and cleaning agents on the floor.</p> <ul style="list-style-type: none"> - First let the floor dry completely and then use a dry cloth to polish out residual quantities of care products and cleaning agents. - Repeat the cleaning process with water and a new cloth (change several times if necessary) until you see an improvement. - If there is no improvement, carry out a thorough clean of the floor before continuing to work with the 2-in-1 wet and dry cleaning attachment.
<p>The moisture film is uneven.</p>	<p>It is possible that the water tank is empty.</p> <ul style="list-style-type: none"> - Check the display on the cordless handheld vacuum cleaner. If it shows the <i>droplet</i> symbol, you need to fill the tank [▶ 57]. - Activate a single application of moisture if you have not done so already, or switch to a suitable moisture setting [▶ 59].
<p>The floor is getting too wet.</p>	<ul style="list-style-type: none"> - Set the 2-in-1 wet and dry cleaning attachment to dry mode [▶ 59]. - Continue working without the automatic moistening function for the time being until the floor appears to be drying.

Fault	Possible cause and rectification
	<ul style="list-style-type: none"> - Then set the 2-in-1 wet and dry cleaning attachment to moisture setting 1 [▶ 59]. It can take a few seconds for more moisture to be added.

Kobold PB7 electric upholstery brush with Kobold MP7/ MR7 mattress cleaning set


CAUTION



Risk of injury from moving parts!

You could injure yourself on moving parts.

- Always switch the device off before all retrofitting, cleaning and maintenance work.
- Disconnect the accessory head from the device before performing retrofitting, cleaning or maintenance work on the accessory head.
- Stay clear of moving parts.
- Never reach into the moving parts.
- Do not operate the electric upholstery brush without an attachment.
- Do not remove mattress-cleaning attachments while the electric upholstery brush is in operation.

Fault	Possible cause and rectification
The electric upholstery brush will not operate.	<p>The cordless handheld vacuum cleaner is not switched on.</p> <ul style="list-style-type: none"> - Switch on the device. <p>There may be a fault on the cordless handheld vacuum cleaner.</p> <ul style="list-style-type: none"> - For instructions on rectifying faults according to error codes, see Troubleshooting [▶ 90] by error code.
The <i>filter bag</i> symbol is flashing. However, the filter bag is not full.	<p>When vacuuming grooves and crevices, the <i>filter bag</i> symbol may flash even though the filter bag does not need to be changed.</p> <ul style="list-style-type: none"> - Move the nozzles gently back and forth as you vacuum.
 <p>The bristles of the electric upholstery brush are distorted or matted.</p>	<p>Fringes or fabrics have been vacuumed up and pulled out again.</p> <ul style="list-style-type: none"> - Replace the suction shoe.
The brushes on the electric upholstery brush no longer rotate.	<p>The cordless handheld vacuum cleaner is not switched on.</p> <ul style="list-style-type: none"> - Switch on the device. <p>The suction shoe is not correctly attached.</p> <ul style="list-style-type: none"> - Lock the suction shoe firmly in place. <p>Something has been vacuumed up that is blocking the brushes.</p>

Fault	Possible cause and rectification
The electric upholstery brush switches off when applying Lavenia.	<ul style="list-style-type: none"> - Switch the cordless handheld vacuum cleaner off. - Disconnect the electric upholstery brush from the cordless handheld vacuum cleaner. - Remove the object that has been vacuumed up. - Connect the electric upholstery brush to the cordless handheld vacuum cleaner again.
	<p>You may have applied pressure. If you apply pressure on the mattress freshening accessory, the automatic electric floor brush will automatically switch off to protect the mattress from getting damaged.</p> <ul style="list-style-type: none"> - Switch the cordless handheld vacuum cleaner off and back on again to continue working with the automatic electric floor brush.

If the fault cannot be rectified, please contact Vorwerk [customer service](#) [▶ 104].

14 Warranty

Any warranty services can be found in the order note or purchase contract.

15 Disposal

15.1 Disposal of the device



This symbol means that electrical and electronic appliances may not be disposed of in household waste. You can return your old electrical appliances to a municipal collection point free of charge.

15.2 Disposal of batteries

The lithium-ion battery contains substances that can be harmful to the environment. Before scrapping the device, the battery must be removed. Only dispose of batteries that are completely empty. The contacts on the battery must not come into contact with metal under any circumstances and should be covered with insulating tape prior to disposal.

The crossed-out bin symbol depicted on a battery or on a rechargeable battery means that the battery/rechargeable battery must not be put into household waste.

The separate collection of old batteries and rechargeable batteries is intended to enable correct recycling and to prevent negative effects on health and the environment.

Batteries and rechargeable batteries must not be disposed of in household waste. You are legally required to return all used batteries and rechargeable batteries.

15.3 Disposal of premium filter bags

Dispose of premium filter bags in household waste.

15.4 Disposal of the packaging

The packaging is an important part of the product. It protects our devices against damage in transit and reduces the risk of a fault. For that reason, we cannot avoid using packaging. The original packaging provides the best protection against damage in transit if you need to send your device to our customer service department.

If you want to dispose of the packaging, please use regional collection points such as waste-paper and recycling containers.

16 Service

For more information, please speak to our UK & Ireland Customer Care team, either by calling +44 330 6600 834 (Monday to Friday 09:00 – 17:00) or sending an email to info@vorwerk.co.uk.

17 Manufacturer and Importer

Manufacturer

Vorwerk Elektrowerke GmbH & Co. KG
Mühlenweg 17-37
42270 Wuppertal
Germany

Importer

Vorwerk UK Limited
Ashurst Manor
Church Lane
Ascot
SL5 7DD

18 Declaration of Conformity

Vorwerk Elektrowerke GmbH & Co. KG hereby declares that the radio equipment type Kobold VK7 cordless handheld vacuum cleaner is in compliance with the Directive 2014/53/EU. The full text of the EU declaration of conformity is available at:

<https://www.vorwerk-group.com/de/home/meta/eu-konformitaetserklaerung>

and <https://www.vorwerk-group.com/en/home/meta/ec-declaration-of-conformity>

